

Victor Pro Video Production Camera Cart (CT-VCTR-PRO-48)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Lower Shelf



Top Shelf



2 x Crossbars



2 x Hinge Handle



Carrying Handle



Allen key L-Type, 4 x Screws



4 x Knobs

All rights reserved.


No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.



2 x Pneumatic Tires With
Break With Packing Pouch



2 x Pneumatic Tires Without
Break With Packing Pouch



4 x (31" Length) Rods With Packing

Victor Pro Camera Cart Setup

NOTE: Two peoples are needed to assemble the cart.

- Open all the 4 locks which are on both sides end of the cart.



- Pull and flip the locking pin in upward direction to open the locks.



- After unlocking all locks, separate the upper and lower shelf.



Pneumatic Tires With break

- Unlock the tire (With brake) by flipping the knob.



- Attach the unlocked tire (With break) on lower shelf's dovetail bracket by sliding on it as shown in the image.



- Flip the knobs to secure the attached tire As shown in image.



- The cart would look like this after attaching both the tires (With break).

NOTE: To keep the cart in static position, lock the wheels by pushing down the lever.



Pneumatic Tires Without Break

- Unlock the tire (non break) by flipping the knob.



- Attach the unlocked tires (non break) on lower shelf's dovetail bracket by sliding as shown in the image.



- The cart would look like this after attaching both the tires (non break).



Rod

- Loose all the 4 knobs of lower shelf's corner hole and insert rod into it, as shown in image.



- Tighten all the knobs provided at each corner of the lower cart. So that all the rods are properly attached to the cart as shown in the image.



Carrying Handle


- Loosen the screw of the carrying handle with the help of Allen key L-type as shown in image.



- Follow the same steps for all screw removal before attaching it to lower shelf.



- Now place the carrying handle on the side of the bottom shelf.



- Now, screw the carrying handle to lower shelf with the help of allen key L-Type.



- Follow same steps for all screws to check whether they are properly set.



Upper Shelf

- Now mount the upper shelf on the top of the rods by aligning it in the corners.



- Tighten all the 4 corner knobs of upper shelf so that upper shelf doesn't fall down.



Crossbar

- Loosen the knob to open clamp of the crossbar.




- Now place the clamps of crossbar on rods, as shown in image.



- Tighten knobs tightly to set crossbar properly on the rods.



- The crossbar would look like this after attaching both clamps, as shown in image.



Hinge Handle

- Loosen the handle to open clamp of hinge handle.




- Place handle clamp on the rod and adjust the hinge handle accordingly.




- Follow same steps to attach second hinge handle.



NOTE: It helps create the leverage needed while lifting the cart quickly over obstacles, stairs or other incline surfaces.



- Unlatch upper shelf's flap by sliding the knob.



- Follow the same step with second knob and open the flap.



- The cart would look like this after following all the steps correctly.



YOUR PROAIM VICTOR PRO VIDEO PRODUCTION CAMERA CART ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.