

Assembly Manual



■ What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Bottom Shelf



Top Shelf

All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.



20" Pneumatic Wheels



9" Dovetail Wheels



4 x Speed Rail Clamps



Speed Rails



Crossbar

4 x knobs & washers
for Speed Rail

2 x Handles



3 x Shelf knobs


Soundchief Cart Setup

9" Dovetail Wheels Assembly

- Unlock the 9" dovetail wheel's lever and attach the wheel by sliding into the cart bottom base and securely tighten it.
- Repeat the same process for the second 9" dovetail wheel.



Feature: The push and pull wheel brake system enables you to securely halt the movement of the wheels.



20" Pneumatic Wheels Assembly

- Insert the bolt into the center of the 20" wheel and then insert the bush from the opposite side, as shown in the image.
- Attach this wheel to the side of the cart and securely tighten the bolt using a 19mm spanner.
- Repeat the same process for the second 20" Pneumatic wheel.



Top Shelf Assembly

- Assemble the top shelf onto the bottom shelf ensuring a proper fit.
- Insert the shelf knobs from both sides and tighten them securely.

Feature: Top shelf can be mounted onto the bottom shelf from both sides.



- Attach the handle onto the top shelf or bottom shelf as per your requirement.




Speed Rail Clamps & Crossbar Assembly

- Loosen the knob of the Speed Rail Clamp and remove the knob along with the washer.



- Slide the Speed Rail Clamp into the crossbar and insert the knob and the washer.

NOTE: Ensure that you slide the Speed Rail Clamp from the flat side.



- After inserting the knob, securely tighten it.



- Repeat the same process to attach the Speed Rail Clamp on the other end of the crossbar.



- Attach the crossbar to the Cart ensuring the threads align after which tighten both the end knobs to secure it.

NOTE: Attach the curved side of the Speed Rail Clamp to the cart; otherwise, the folding shelves will not fold correctly.




NOTE: The Cart features two vertical poles at the back for holding a crossbar to mount multiple monitors.



- Attach the single speed rail clamp to the cart ensuring their threads align, then insert the speed rail knob and securely tighten it .



- Repeat the same process to attach the second clamp.




Speed Rail Mounting

- Loosen the knob of both the Top and bottom clamp.



- Now, insert the Speed rail into the clamps.



- After inserting the Speed rail, tighten both the top and bottom knobs to secure it.
- Repeat the same process to insert the second Speed rail.



Collapsible Side Wings

- Extend the collapsible side wings by pulling them up.



- After opening the shelf, be sure to secure it by locking it.



Rotation of Top Shelf Towards Dovetail wheels

- Loosen and remove all the shelf knobs.
- Repeat the same process to remove the knobs from the other side of the shelf.
- Now, rotate the Top shelf and mount it on the bottom shelf.
- Then, insert all the shelf knobs and securely tighten them.




Handle Assembly

- Twist the handle to the left to loosen it and then open the speed rail clamp.
- Now, attach the handle to the speed rail using the speed rail clamp.
- Then twist the handle to the right to securely tighten it.
- Repeat the same process to attach the second handle.



NOTE: You can adjust the handle position according to your requirement.



YOUR PROAIM SOUNDCHIEF CART VERTICAL WORKSTATION ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer a one-year warranty for our products from the date of purchase. Within this period, we will repair it without charge for labor or parts. The warranty doesn't cover transportation costs, nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subject to inspection and evaluation by us.

Liability: We are not liable for damage caused by products we do not supply or from mishandling in transit, accident, misuse, neglect, or lack of care of the product or service by anyone other than our company.

Contact Us: If you are dissatisfied, please contact us immediately. We promise our utmost support and care until you use our product.