www.ravpower.com




Model: RP-BCOO2 RP-BCOO2 Savior Series Nikon EN-EL14 Dual 1100mAh Rechargeable Batteries and Charger Set

User Guide

Package Contents

- 1) 2 x 1100mAh Replacement Batteries for Nikon EN-EL14
- 2 1 x DC Dual Battery Charger
- 3 1 x Micro USB Cable



Specifications

Model	RP-BCOO2
Capacity	2 x 1100mAh / 8.14 Wh
Dimensions	5.28 x 3.78 x 1.4 cm / 2.07 x 1.49 x 0.55 in
Weight	155 g / 3.38 oz

How to Use

- · Connect the USB charger to a power outlet.
- · The indicator light becomes green.
- · Insert the battery.
- · When charging, the indicator light becomes red.
- · When battery is fully charged, the indicator becomes green again.

FAQ

- Q: Can I use the charger to charge original Nikon batteries?
- A: Yes.
- Q: What charger can I use to charge the batteries?
- A: You can use USB chargers, power banks, or car chargers. We recommend using 2A DC and 2.4A DC chargers.
- Q: How long does it take to get fully charged?
- A: Fully charge 1 battery: 2.5 hours.
 Fully charge 2 batteries simultaneously: 3 hours.
- Q: Can I put the batteries into the camera to charge? $\Delta \cdot \vee_{es}$