

www.ravpower.com

RAVPOWER


RP-PB057_V1.3 EN

Model: RP-PB057
RP-PB057 Savior Series Nikon EN-E15 Dual
2100mAh Rechargeable Batteries and Charger Set

User Guide

Package Contents

- ① 2 x 2040mAh Replacement Batteries for Nikon EN-EL15
- ② 1 x DC Dual Battery Charger
- ③ 1 x Micro USB Cable



Specifications

Model	RP-PB057
Capacity	2 x 2040mAh / 14.7Wh
Dimensions	5.57 x 3.92 x 1.98 cm / 2.19 x 1.54 x 0.78 in
Weight	154 g / 5.5 oz

How to Use

- Connect the USB charger to a power outlet.
- The indicator light becomes green.
- Insert the battery.
- When charging, the indicator light becomes red.
- When battery is fully charged, the indicator becomes green again.

FAQ

Q: Can I use the charger to charge original Nikon batteries?

A: Yes.

Q: What charger can I use to charge the batteries?

A: You can use USB chargers, power banks, or car chargers. We recommend using 2A DC and 2.4A DC chargers.

Q: How long does it take to get fully charged?

A: Fully charge 1 battery: 4 hours.

Fully charge 2 batteries simultaneously: 5 hours.

Q: Can I put the batteries into the camera to charge?

A: Yes.