

Care Instructions

Please read these instructions before use of this product. Keep this instruction sheet as it contains important information.



- Wash before use (Boiling is not necessary).
- DO NOT use this product for purposes that are not originally intended.
- DO NOT use over direct heat.
- DO NOT use this product once it's damaged.
- Handle broken pieces carefully.
- DO NOT drag on surfaces that can be easily scratched.
- Wash promptly after each use.

- Wash with a soft sponge and a neutral kitchen detergent, rinse, and dry well before storing.

- DO NOT use a scouring cleanser or a stainless steel scrubber.

- For tough stains, like tea incrustation, use a kitchen bleach properly.

- It may get gray marks from rubbing against metalware. Hand wash these marks with a soft sponge and a cleanser as they will not come off with a neutral kitchen detergent. However, tough gray marks may not come off completely.

- This product may have crystallized glazes on the surface. The density and amount of the crystallized glazes may vary, but they are not flaws.