



Care Instructions

Please read these instructions before use of this product.
Keep this instruction sheet as it contains important information.



- Wash before use (Boiling is not necessary).
- **DO NOT** use this product for purposes that are not originally intended.
- **DO NOT** use over direct heat.
- **DO NOT** use this product once it's damaged.
- Handle broken pieces carefully.
- **DO NOT** drag on surfaces that can be easily scratched.

- Wash promptly after each use.
- Wash with a soft sponge and a neutral kitchen detergent, rinse, and dry well before storing.
- **DO NOT** use a scouring cleanser or a stainless steel scrubber.
- For tough stains, like tea incrustation, use a kitchen bleach properly.

- It may get gray marks from rubbing against metalware. Hand wash these marks with a soft sponge and a cleanser as they will not come off with a neutral kitchen detergent. However, tough gray marks may not come off completely.