# **ASSEMBLY INTRUCTIONS**

PF20305

NO.	PART	QTY.	
Α		1	Back Board
В	A A A A A A A A A A A A A A A A A A A	1	Back Holder
С		1	Right Armrest
D		1	Left Armrest
E		1	Seat Board
F		2	Back Holder Cap
G		1	Cross Tube
Н		2	Washer
AA	M6*30	10	Screw
BB	<b>◯</b> M6*15	6	Screw
СС	M6*40	2	Screw
DD		2	Screw Cap
FF	ø13*ø6.5*1.0	2	Washer
GG	ø6.0*ø9*1.5	2	Washer
НН		1	Hex Key
II	2	1	Allen wrench


STEP.3

# F B

Put F into the B


### STEP.2

STEP.1



Connect A and B with CC&FF&GG&DD, two sides together. If will be used this step.

The Screws have to be in halfway, not to the end.



Connect E and C with AA&BB.

The Screws have to be in halfway,not to the end.

## ► Safety and Care Advice

- Please check and make sure you have all the parts indicated before you start with the assembly.
- Assembly work should be performed on a soft surface to prevent the finish to be scratched during assembly.
- Easy wipe clean with a dry or slightly damp cloth. Do NOT use chemical products.
- Please make sure there's no sharp objects (e.g. garden tools, knives and etc.) careful when sitting on the furniture for your own safety. Such items might tear down fabrics or pierce through resin weave, causing permanent damages.
- We recommend furniture to be covered or put away when not in use, in order to prolong product life.

# ► Consejos de seguridad y cuidado


- Antes de comenzar a ensamblar este producto, asegúrese de contar con todas las partes necesarias.
- Es conveniente ensamblar este producto sobre una superficie suave para no raspar el acabado.
- Límpielo con un paño seco o ligeramente húmedo. No utilice productos químicos.
- Debe tenerse cuidado al sentarse sobre el mueble con algún objeto cortante (herramientas de jardinería y cuchillos) en sus bolsillos, ya que pueden desgarrar las telas y penetrar el tejido de resina, lo que lo dañará irreparablemente
- Recomendamos guardar los muebles cuando no estén en uso para prolongar su vida útil

Festival Depot www.festival-depot.com info@festival-depot.com Pomona, CA


# **ASSEMBLY INSTRUCTIONS**


PF20305

### STEP.4



Connect E and D with AA&BB.
The Screws have to be in halfway, not to the end.





Enjoy your lounge.

When A&G&C&D connect well, tighten all screws to the end.

ASSEMBLY TIPS: Please use the hardware and accessories included in the set. DO NOT use other electrical or manual tools.

In order to facilitate the assembly and make your final product firm and stable, please tighten by a few rounds each screw one by one. After all screws are connected, then you start to tighten each screw to the end.

### DO NOT tighten any screw to the end before you've connected all screws.

The assembly requires minimal level of DIY skills if you follow the instructions carefully. In case you encounter any difficulty or have any questions, feel free to contact the store or manufacturer.

# Packing List

			PF20305
NO.	PART	QTY.	
Α		1	Back Board
В	E Add Paga	1	Back Holder
С		1	Right Armrest
D		1	Left Armrest
E		1	Seat Board
F		2	Back Holder Cap
G		1	Cross Tube
Н		2	Washer
AA	M6*30	10+3	Screw
BB	M6*15	6+1	Screw
CC	M6*40	2+1	Screw
DD		2+1	Screw Cap
FF	ø13*ø6.5*1.0	2+1	Washer
GG	ø6.0*ø9*1.5	2+1	Washer
нн		1	Hex Key
	Seat Cushion Back Cushion	1+1	Cushion
		1	Allen wrench

ASSEMBLY TIPS: Please use the hardware and accessories included in the set. DO NOT use other electrical or manual tools.

In order to facilitate the assembly and make your final product firm and stable, please tighten by a few rounds each screw one by one. After all screws are connected, then you start to tighten each screw to the end.

### DO NOT tighten any screw to the end before you've connected all screws.

The assembly requires minimal level of DIY skills if you follow the instructions carefully. In case you encounter any difficulty or have any questions, feel free to contact the store or manufacturer.