




miroir

Miroir M700S Projector


Quick Start Guide

Your Miroir M700S Projector



- A** Audio Out (3.5mm) - (Optional) Connect an external speaker or headphones.
- B** USB Media Reader Jack - Plug a USB stick into the port and play movies, or share pictures.
- C** HDMI Video Input - Connect an HDMI cable to a device that supports HDMI video output.
- D** Reset Button
- E** Power Port - Connect included AC Adapter for power. DC In - 19VDC@3.7A
- F** RJ45 Connector - To connect to the internet
- G** Power Button - Turn the projector on/off
- H** Rubber Foot Pads - Provides stability and proper airflow to cooling vents.
- I** Kickstand - To adjusting the image angle
- J** Tripod Mount
- K** Cooling Vent - **IMPORTANT:** Do not cover or block airflow to the vent.


Remote Control




- A** Power
- B** Main Screen
- C** Volume +/-
- D** Focus Adjust
- E** Direction
- F** Confirm
- G** Back
- H** Projector Settings

Connecting Your Projector with a Cable


Connect To Your Laptop HDMI




Connect To Your Device



Connect To Your MacBook USB-C




Connect To Your Apple Device Lightning



IMPORTANT! Not all USB - C cables will support video.

Connect To Your Streaming Stick HDMI



Connecting Your Projector Wirelessly

WIFI

- Connect the M700S to your WIFI network. Open Settings, and select WIFI and follow the instructions.
- Update the projector if prompted
- Open the SYNQ TV App
- Connect to the available streaming services (not included); a streaming service subscription is required to stream with SYNQ TV
- Once you've logged into your streaming account, start streaming!
- Live TV and Apple TV + are not supported now; please check our website for release dates.

Screen Mirroring

*YouTube; TikTok is supported to play content. *Netflix and other streaming services are not supported*

- Connect your iOS, Android, Laptop, or Tablet wirelessly via the device mirroring option.
- Netflix and other services do not support Screen Mirroring because of Digital Rights Management (DRM)
- Local photos and videos you have taken support Screen Mirroring.
- Some Apps, such as YouTube and TikTok, will support screen mirroring because they are not restricted by DRM.

Adjust the Projector Image

Keystone (under Settings)

- The projector will auto keystone to 6-points, or you can manually adjust under settings.

Zoom (under Settings)

- Depending on your projector's distance from the wall, use the zoom feature to adjust the image size.

Troubleshooting

The image is blurry

- Adjust the projected image's focus using the remote under settings.
- Check that the surface you are projecting on is smooth and non-reflective.
- Check that the projector's lens is clean and free of debris.

The image is not square

- Check that the projector's lens is parallel to your projection surface and that your projection surface is flat.

No sound

- Check the volume control on your source device to ensure the volume is turned up.
- If you are using an adapter, verify that the adapter supports audio.
- Check that the HDMI cable is fully plugged into the HDMI port.

No Signal Message

- Check that you are using the required cable and/or adapter.
- If you are using a digital AV adapter, check that the adapter is an authentic Apple adapter and is compatible with your model phone or tablet.
- If you are connected to a laptop or computer, check your computer display settings to ensure a multiple display option is selected (such as "mirror these displays").
- Check that your source device supports HDMI video out.

Projector will not power on, or stay powered on

- Check that the AC Power adapter is securely plugged into the projector and the wall outlet.

Support

Text Miroir Support **1-855-676-0972**

Download your manual at **www.miroirusa.com/M700S-manual**

miroir

www.miroirusa.com

M700S.11.2022

HDMI[®]
HIGH-DEFINITION MULTIMEDIA INTERFACE

© 2022 Miroir USA, LLC. All rights reserved. Miroir and the Miroir Logo are owned by Miroir USA, LLC. All other trademarks are the property of their respective owners. Miroir USA, LLC assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.