

# LIFEGARD DIGITAL THERMOMETER/HYGROMETER

# **FEATURES:**

- Large Face Digital Thermometer
- Displays Inside (Room) & Outside (Aquarium or Greenhouse) Temperature
- Degree F or Degree C (Accuracy: +/- 1 Degree C)
- Humidity (Accuracy: +/- 5% RH)
- Minimum/Maximum Temperature and Humidity
- Clock 12/24 Hour, Alarm, Calendar Function
- Plastic Coated Probe
- Includes AAA Battery
- Pop up Stand or Hanging Tab

# INSTRUCTIONS

MODE BUTTON: Use to switch from clock to alarm, set current time, alarm time, 12 or 24 hour time, and date.

MEMORY BUTTON: Press to display minimum and maximum temperature and humidity in memory or to erase the previous values keep the button pressed for 2 seconds on the related screen.

ADJ BUTTON: Use to adjust values of set items

### **BATTERY INSTALLATION:**

- Open pop up stand and push and slide to remove battery cover
- Install AAA battery and replace battery cover

#### **CLOCK FUNCTION:**

 Press and hold MODE button for 2 seconds until the minutes flash and adjust to desired time using the ADJ button. Press the MODE button again until the hours flash and adjust to the desired time using the ADJ button. Repeat to adjust to 12 or 24 hour time and date

## MINIMUM/MAXIMUM MEMORY FUNCTION:

 Press MEMORY button to display maximum temperature and humidity, press button again to display minimum temperature and humidity. Press and hold MEMORY button for more than 2 seconds to memorize maximum/minimum values. For example: to erase the MAX memory press the button to get to MAX memory screen and press it again and keep it pressed for 5 seconds.

## **RESET FUNCTION:**

 Open pop up stand and press reset button with the end of a paper clip when first using the product, replacing the battery, or any malfunction.

# °F / °C FUNCTION:

- Open pop up stand and push °F/°C button with end of paper clip to set desired temperature scale.
- facebook.com/lifegardaquatics
- #lifegard\_aquatics



WWW.LIFEGARDAQUATICS.COM INFO@LIFEGARDAQUATICS.COM



