

IPM+ IR Codes

Switch #	HD2600 Command	HD2600 IR Command
Switch 1	Power On/Off	0x01FE
Switch 2	Eject	0x04FB
Switch 3	Play/Pause	0x12ED
Switch 4	Stop ■	0x16E9
Switch 5	▶▶	0x13EC
Switch 6	◀◀	0x11EE
Switch 7	▶▶	0x17E8
Switch 8	◀◀	0x15EA
Switch 9	Menu	0x0DF2
Switch 10	Enter	0x0AF5
Switch 11	↑	0x06F9
Switch 12	↓	0x0EF1
Switch 13	Setup	0x0FF0
Switch 14	Return	
Switch 15	Subtitle	0x07F8
Switch 16	Repeat	0x18E7
Switch 17	Display	0x05FA
Switch 18	Volume up	0x08F7
Switch 19	Volume Down	0x0CF3
Switch 20	Mute	0x10EF