


## 2P Battery Harness 6942



**Caution:** Battery and ESC connections must follow standard convention as above. **All batteries must be at full charge before connection.**

**DO NOT CHARGE WHILE CONNECTED.**

**6942** - Battery Harness, 2P, for two packs in parallel.  
Use to increase current and duration.

**6952** - Battery Harness, 2S, for two packs in series.  
Use to increase the total voltage.

**6953** - Battery Harness, 3S, for three packs in series.  
Use to increase the total voltage.


**Caution:** All batteries **MUST** be identical, same brand, "C", rating and mAh rating.



[www.mpihobby.com](http://www.mpihobby.com)

**MPI**

## 2P Battery Harness 6942



**Caution:** Battery and ESC connections must follow standard convention as above. **All batteries must be at full charge before connection.**

**DO NOT CHARGE WHILE CONNECTED.**

**6942** - Battery Harness, 2P, for two packs in parallel.  
Use to increase current and duration.

**6952** - Battery Harness, 2S, for two packs in series.  
Use to increase the total voltage.

**6953** - Battery Harness, 3S, for three packs in series.  
Use to increase the total voltage.


**Caution:** All batteries **MUST** be identical, same brand, "C", rating and mAh rating.



[www.mpihobby.com](http://www.mpihobby.com)

**MPI**

## 2P Battery Harness 6942



**Caution:** Battery and ESC connections must follow standard convention as above. **All batteries must be at full charge before connection.**

**DO NOT CHARGE WHILE CONNECTED.**

**6942** - Battery Harness, 2P, for two packs in parallel.  
Use to increase current and duration.

**6952** - Battery Harness, 2S, for two packs in series.  
Use to increase the total voltage.

**6953** - Battery Harness, 3S, for three packs in series.  
Use to increase the total voltage.


**Caution:** All batteries **MUST** be identical, same brand, "C", rating and mAh rating.



[www.mpihobby.com](http://www.mpihobby.com)

**MPI**

## 2P Battery Harness 6942



**Caution:** Battery and ESC connections must follow standard convention as above. **All batteries must be at full charge before connection.**

**DO NOT CHARGE WHILE CONNECTED.**

**6942** - Battery Harness, 2P, for two packs in parallel.  
Use to increase current and duration.

**6952** - Battery Harness, 2S, for two packs in series.  
Use to increase the total voltage.

**6953** - Battery Harness, 3S, for three packs in series.  
Use to increase the total voltage.

**Caution:** All batteries **MUST** be identical, same brand, "C", rating and mAh rating.



[www.mpihobby.com](http://www.mpihobby.com)

**MPI**