

Installation & Service Instructions


Pool Table Lights

- PLEASE READ CAREFULLY BEFORE INSTALLING -

INSPECTION: *Remove Reinforced Tape From Bulb Before Plugging In.* Test illumination by plugging lamp into proper 120v/60hz AC electrical outlet. If lamp does not light pull the switch chain. If lamp still does not light, inspect for damage and follow inspection report procedure. Damage in shipment should be reported to the delivering carrier immediately and a claim report entered.

CEILING INSTALLATION: The sign is for **INDOOR USE** only. Hang from a surface that can adequately support the sign's weight of approximately 25 lbs. Place sign away from direct sunlight and any heat source. Install as follows:

1. Unplug lamp before installing. **Always disconnect lamp from electrical outlet when handling.**
2. Mark points on ceiling for screw hook mounts (not included) that are in line with center of the pool table and spaced apart 12" on each side from center to align with hanging cables on the top of the lamp.
3. Install screw hooks. Make sure the mounts will securely hold the hanging lamp. If necessary, use eye bolts with toggle or molly (hardware not included), depending on ceiling construction.
4. Attach cables to screw hooks.



OPERATION & SERVICING: Check that the reinforced tape has been removed from the bulbs before plugging in. With lamp hanging, plug into a common 120v/60hz grounded AC electrical outlet. **Disconnect lamp from electrical outlet before servicing.** Replace fluorescent bulb with appropriate replacement bulb.

CLEANING: **Disconnect sign from outlet before cleaning.** Wipe sign with soft cloth to remove dust. A mild solution of liquid detergent may be used to remove stubborn stains. Avoid excessive rubbing. Do not use abrasives or strong chemicals. Dry with a soft, clean cloth.

The Fan-Brand Limited Warranty

All signs manufactured by The Fan-Brand, are guaranteed to be free from manufacturing defects for a period of one (1) year from date of manufacture, unless otherwise specified.
Breakage of lamps and other materials are not covered by this warranty.

The Fan-Brand's obligation hereunder is limited to the replacement of parts only. If a particular product is found to be inoperative or defective, permission and instructions as to where it is to be sent **MUST** be obtained from the Customer Service Department. Only then should it be returned to our location as information directs.

Customer is responsible for immediately opening carton and inspecting for concealed damage and notifying the carrier within 15 days of receipt of product for any damage noticed upon arrival (including lamps).

The Fan-Brand will warrantee shipping damage not covered by the carrier, but only if the carrier was notified within the 15-day period. Products must be returned prepaid.

This guarantee is void in case of negligent use or misuse, repair, alteration or disassembly by unauthorized personnel or operation by improper voltage or use contrary to instructions.

This warranty does not cover loss or damage due to accidents involving the product, acts of criminal aggression, other property disasters or acts of God. Except for those warranties specifically and expressly set forth above, seller disclaims any and all warranties expressed, implied or statutory, including but not limited to all warranties of merchantability and fitness for a particular purpose.

CUSTOMERSERVICE@THEFAN-BRAND.COM