

# FOLDING ARM AWNING MOTOR SELECTION CHART



The following chart is a guide only.  
Refer to the hardware manufacturer for more details.

## HOW TO USE THIS SELECTION CHART

- Refer to the chart that corresponds to the projection required.
- Select the tube size from the left hand column.
- Select the motor suitable by matching the arms & tube size together.
- A safety factor has already been incorporated.
- Installation length shown in metres.

### Projection up to 1.5m

Tube Diameter (mm)	Number of Arms -->		Installation length (m) -->	
	2	4	6	8
ø 63/70	25 Nm	40 Nm	50 Nm	80 Nm
ø 78	30/35 Nm	40 Nm	60 Nm	

### Projection up to 2m

Tube Diameter (mm)	Number of Arms -->		Installation length (m) -->	
	2	4	6	8
ø 63/70	25 Nm	40 Nm	50 Nm	80 Nm
ø 78	30/35 Nm	40 Nm	60 Nm	

### Projection up to 3m

Tube Diameter (mm)	Number of Arms -->		Installation length (m) -->	
	2	4	6	8
ø 63/70	40 Nm	50 Nm	80 Nm	100 Nm
ø 78	50 Nm	80 Nm	100 Nm	120 Nm

### Projection up to 5m

Tube Diameter (mm)	Number of Arms -->		Installation length (m) -->	
	2	4	6	8
ø 63/70	50 Nm	80 Nm	100 Nm	
ø 78	80 Nm	100 Nm	120 Nm	