

## 6. SETTING THE LIMITS

Use the tool provided to set the up and down limit switches. Refer to the figures below.

On the limit setting diagram there are two arrows pointing towards each other. These indicate the direction of motor rotation (not the direction of shutter travel).

To adjust the limit switches: 1) Pick the direction of motor rotation that requires adjustment.  
2) Adjust the appropriate screw. Plus (+) will add travel. Minus (-) will reduce travel.

