




T10

True Wireless Earbuds

User Manual


PACKAGE LIST



Wireless Earbud * 2
 Magnetic Charging Case * 1
 Ear Tips * 3 (S/M/L)



User Manual * 1




Type-C Charging Cable * 1

IMPORTANT NOTES

- 1 Register your product on www.tranya.com to get an EXTRA three-month warranty for free.
- 2 Before using the T10 wireless earbuds, please charge both the case and earbuds.
- 3 We provide three pairs of rubber eartips (including the set installed on the earbuds), please choose the best fit for you.



- 5 If the right and left earbud don't sync, please reset the earbuds.
- 6 If the earbuds don't charge, please clean the charging slot on the case and the contact face on the earbuds.



TOUCH CONTROL

- Play / Pause: Press and hold for 1 second (L/R)
- Next/Previous track: Tap three times (R/L)
- Volume up/down: Tap twice (R/L)
- Active Siri/other voice control software: Tap 4 times(L/R)
- Reject/End a call: Press and hold for 1 second (R/L)
- Answer a call: Tap (L/R)

GAME MODE


Game Mode
 [Automatically return to normal mode after power off]

Normal/BASS BOOSTED MODE

Normal/Bass Boost Mode

WEARING

- 1 Put the earbuds into your ear.
- 2 Rotating the earbuds to auricle side to fit snugly.



For more information, please visit:
www.tranya.com
 For any assistance, email us:
support@tranya.com

Made in China
 FC CE RoHS

POWER ON

- Automatically
- Manually (Long press and hold for 4 seconds)

POWER OFF

- Automatically
- Manually (Long press and hold for 4 seconds)

Note: When the charging case is at low power or out of power, the earbuds will not automatically power on/off, please power them on/off manually.

HOW TO RECONNECT THE EARBUDS

- If you can't get the two earbuds sync, please reconnect the earbuds to solve the issue.
- 1 Pick the earbuds out of the charging case, and long press and hold for 4s to power then off.
 - 2 After power off the earbuds, long press both earbuds for 6 seconds until you see the light blinks times.
 - 3 Pick up the earbuds and reconnect it to your device.

PAIR THE EARBUDS WITH YOUR PHONE

- 1 Power on the earbuds and turn on Bluetooth.
- 2 Select "Tranya T10" and confirm.

CHARGING

- 1 Charging the Earbuds
- 2 Charging the Case

FAQ

- Q: Why does signal interruption occur in some places, such as along the railway, at the airport?
 A: There're usually lots of cables underlying in the places mentioned above, so are more likely to produce electromagnetic interference and results in the signal interruption. If the earbuds cut in and out frequently during routine use, you may have a defective item. Please contact us. We do our best to respond to all inquiries within 12 hours.
- Q: My earbuds don't charge, what can I do?
 A: Please try to follow the below steps:
 1. Clean the charging slot on charging case.
 2. Clean the charging connector on earbuds.

FAQ

- Q: Why my earbuds don't power on/off automatically?
 A: The earbuds would not power off automatically when the case is at low power or out of power. Please recharge the case. And you can long press for three seconds to power on and long press for four seconds to power off the earbuds.
- Q: Will the Bluetooth mouse cause the signal interference?
 A: Maybe. If your Bluetooth mouse and earbuds connect to the same device.