THIS MANUAL APPLIES TO THE FOLLOWING BLAZE GRILLS

Model: BLZ-4LTE2MG / 4 BURNER **Cutout Dimensions** 30 5/8"W x 21 1/4"D x 8 1/2"H *These dimensions create the required air gap underneath this appliance. This air gap serves multiple purposes, such as preventing a build-up of heat in the island cavity and helping provide proper airflow for combustions and/or cabinetry. BTU Output 14,000 BTU per Burner x4 Infrared Back Burner 10.000 BTU Total BTU 66,000 Push N' Turn Flame Thrower Primary Ignition Secondary Ignition Flash Tube Cooking Grid 29 1/2" X 17 7/8" Dimensions 740sq.in **Total Cooking Area** (includes warming rack) Flame Tamer Flame Stabilizer Grid Removable Heat Zone Separators Zone Cooking Rotisserie Kit Optional (Motor & Forks) Commercial Quality Cast Stainless Steel Burner Each grill contains an NG/LP Orifice Kit Gas Type In addition to the parts warranty found below, Blaze Outdoor Products will cover up to \$120 in labor per warranty claim in a 30-day period for the first 365 days from purchase date. (Blaze will not reimburse for any diagnostic charges). Please call our customer service department for help diagnosing the issue before calling a service provider. Warranty *Limited Lifetime – Defects in manufacturing and workmanship. Cooking grids, Flame Tamers, Heat Zone Separators, Stainless Housing, Valves, and Stainless Burners against rust- through. *1 Year – Ignition Components, Electronics and Lighting systems *Appliances must be registered within 30 days of purchase to validate this warranty.

*See warranty section for details.

BBQ SPECIFICATIONS

NOTE: ALWAYS have equipment measured by Contractor before beginning any project.

*These dimensions create the required air gap underneath this appliance. This air gap serves multiple purposes, such as preventing a build-up of heat in the island cavity and helping provide proper airflow for combustions and/or cabinetry.

BLZ-4LTE2MG

