




License Plate Light Install Instructions

(Part #: 69270-XX)

PARTS / TOOLS NEEDED:

	<p>Affix with screws appropriate in length and thread for the mounting surface. Lamp mounting features sized for #6, or #8 pan head screws.</p>	<p>Power Drill</p>	<p>Butt Splices & Application Specific Sealant</p>
<p>License Plate Light</p>	<p>Not Provided</p>	<p>Not Provided</p>	<p>Not Provided</p>

Safety Instructions

- Disconnect power before installing, adding or changing any component.
- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not install any luminaire assembly closer than 6" from any combustible materials.
- Positive (+) outputs require a fuse if the attached wire leads are not rated to handle the max current.


****DOT:** 8 Lux min on plate. Light must be mounted 3-4" to the side of license plate.



1. Determine the installation location drill a hole for the wires then align the light in the wire hole and use the light to mark screw holes. Drill appropriate sized holes for mounting screws.



2. Follow the wiring diagram below to wire the light to your system.



3. Feed the wires back through the hole and use application specific sealant around wire hole.



4. Screw the light in place using the screws provided.



For warranty information please visit www.itc-us.com

3030 Corporate Grove Dr • Hudsonville • MI • 49426

Phone: 616-396-1355 • www.itc-us.com • sales@itc-us.com • DOC#: 710-00159 • Rev A: 01.16.20