



## LED Down Light Installation Instructions

(Part # 69307)



### Product Safety Instructions

**IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.**

- \*Disconnect power before installing, adding or changing any component.
- \*To avoid a hazard to children, account for all parts and destroy all packing materials.
- \*Do not use in damp or wet locations unless specified otherwise.
- \*Do not install any luminaire assembly closer than 6" from any curtain or other combustible material.

#### SERVICE

There are no user-serviceable parts inside. Opening unit will void warranty.

#### WARRANTY

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

### Installation Instructions:

- Step 1: Remove decorative bezel
- Step 2: Cut hole in mounting surface using 0.75" hole saw.
- Step 3: Attach wires to the power source - if the wires on the light are red/black the red is positive and black is neutral. If the wires are white/black then white is neutral and black is positive.
- Step 4: Insert into mounting hole and tighten to the surface with screws
- Step 5: Push decorative bezel back onto light

\*\*LEDs are polarity sensitive and will not light if not attached properly

