



## Push Lens Switch Courtesy Light Installation Instructions

(Part #'s 69331, 69330, and 81330)



### Product Safety Instructions

**IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.**

- \*Disconnect power before installing, adding or changing any component.
- \*To avoid a hazard to children, account for all parts and destroy all packing materials.
- \*Do not use in damp or wet locations unless specified otherwise.
- \*Do not install any luminaire assembly closer than 6" from any curtain or other combustible material.

#### **SERVICE**

There are no user-serviceable parts inside. Opening unit will void warranty.

#### **WARRANTY**

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

### Installation Instructions:

- Step 1: Turn bezel counterclockwise to remove
- Step 2: Drill hole in mounting surface with 2.125" hole saw
- Step 3: Attach wires to power source - if the wires on the light are red/black the red is positive and black is neutral. If the wires are white/black then white is neutral and black is positive.
- Step 4: Install using included screws
- Step 5: Turn bezel clockwise to replace

\*\*All electrical connections should be made inside a watertight junction box.

