



Hatch Lift Pins Installation Instructions

(Part # 84250)



Product Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

*To avoid a hazard to children, account for all parts and destroy all packing materials.

SERVICE

There are no user-serviceable parts inside. Opening unit will void warranty.

WARRANTY

For information on our warranty policy please visit our website at <http://www.itc-marine.com/resources/warranty/>

Installation Instructions:

- Step 1: Drill ¼" hole in mounting surface
- Step 2: Split spring at the base of the rod and spin to remove
- Step 3: Remove washer
- Step 4: Insert rod through mounting surface
- Step 5: Replace washer
- Step 6: Replace spring

