

# Pivot™ Flip Drain Assembly Installation Instructions

(Part #'s 98110 & 98120)



## **Product Safety Instructions**

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

\*To avoid a hazard to children, account for all parts and destroy all packing materials.

#### **SERVICE**

There are no user-serviceable parts inside. Opening unit will void warranty.

#### WARRANTY

For information on our warranty policy please visit our website at http://www.itc-marine.com/resources/warranty/

### **Installation Instructions:**

- Step 1: Remove elbow, brass flange, and two rubber gaskets from drain assembly.
- Step 2: Insert drain from inside sink making sure the sink walls fit in between the layers of the top gasket to provide a watertight seal (See Fig. A.) (This gasket can be removed and plumbing silicon can be used instead of the gasket)
- Step 3: Replace gasket to bottom side of sink (Fig. B) (two are provided and both may be used, depending upon sink wall thickness)
- Step 4: Replace brass flange (Fig. C) & tighten complete to compress gaskets to ensure a watertight fit
- Step 5: Determine desired draining system and attach either straight drain pipe (outer threads) into P-Trap or Elbow (internal threads into flexible drain line)

