







Cypress™ Table Leg Installation Instructions

(Part #'s: CAXX-FLL-SC)


PARTS/TOOLS NEEDED:

			# 10 Pan Head Screws # 10 Oval Head Screws # 12 Oval Head Screws	
Table Base	Floor Base	Table Leg	Screws (Not Provided)	Power Drill (Not Provided)


INSTALLATION CONSIDERATIONS

- To avoid a hazard to children, account for all parts and destroy all packing materials.
- Do not sit on or lean on table, intended for use as a table only.
- The stiffness and rigidity of the floor mounting substrate has a direct effect on the sturdiness of the entire table system.

1. Mount the floor base into solid floor structure (such as wood) using #12 phillips oval head screws.



2. Align the T-bolt on the bottom of the leg with the rectangular opening in the floor base. Insert the T-bolt, press and hold the button and begin to turn. After one turn, pull up on the leg to ensure that the T-bolt is secure in the floor base. Continue to turn the leg until the leg is secure.



Ensure the T-bolt is 3/8" away from the bottom of the leg



3. Mount the table base onto table top (customer provided) using designated screw based on material of the base. Make sure the weight of the table top is evenly supported over the table leg. Then align the table base to the leg and push down.

Table Base Material	Screw Type Needed
Black Plastic (TS4002)	#10 Pan Head Screws
Die Cast Aluminum (TS5030-Y)	#10 Oval Head Screws




*To ensure the table base is secure to the table leg make sure the table base goes over the first black piece.

Removing The Leg & Table Base

- 1 To remove the table base, press the button at the top of the post.
*First twist until it releases from taper fit then lift until it pops off the post.
- 2 To remove the leg, press the button, then turn the leg counter-clockwise and lift gently until the leg removes from the base
- 3 Place cover on floor base when the leg is not in place.



*The button must be held down until the base pops off.



For warranty information please visit www.itc-us.com/warranty

3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • www.itc-us.com • sales@itc-us.com • DOC #: 710-00122 • Rev B • 10/14/21