



UltiMount S2

PART NUMBER: UL-222

Flex Pad Removal Instructions:

Please read all instructions thoroughly before attempting

Step 1 If the mounting surface appears to be highly decorative, no removal tools are recommended. Remove by hand and proceed with caution. If the mounting surface is vinyl, a blunt instrument may help to remove the flex pad. A kitchen spoon may work well. Avoid using tools with sharp edges that may damage the mounting surface.


Step 2 Warm the Flex Pad with a hair dryer for 2 to 3 minutes. Once the flex pad has been heated, the adhesive will soften. Caution: Too much heat may damage the vehicle or mounting surface. Do not use a commercial heat gun or paint stripping gun as these will create excessive heat.

Step 3 Lift one edge of the flex pad gently with your fingers or the rounded edge of the spoon. Once enough of the edge is peeled up to grip with your fingers, pull the flex pad gently at a 90 degree angle from the mounted surface until removed.

Step 4 In most cases there will be no adhesive left on the mounting surface. If you find that adhesive remains, it can be easily removed by rubbing your thumb or finger across the surface repeatedly.

Optional Accessories Sold Separately

| | |
|---------------------------------|-----------------------------------|
| T-Amps Adapter Plate | <i>m</i> iMount iPod Cradle |
| <i>m</i> iGrip Universal Holder | <i>m</i> iniGrip Universal Holder |
| Express Mount | Extension Bracket |



Bolt-on Plate Available at www.pro-fit-intl.com

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Universal Mount®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.368.0073 Fx: 651.688.9876

© Pro.Fit International, Eagan, MN 2007

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM