



S920M Smart Clip

Apple: iPhone (2G, 3G, 3G S, 4, 4s, 5, 5c, 5s, 6, 6s, 7, 8, SE, X, XS);

Samsung: Galaxy S (S5 mini, S6, S6 edge, S7, S9, S10e) Galaxy A (A3 2015, A3 2016, A3 2017, A5 2017, A20e 2019, A40 2019), Galaxy C5 pro, Galaxy J (J2 2015, J2 2016, J2 Core 2018, J2 Pro 2016, J2 Pro 2018, J3 2018, J5 2017, J5 Prime), Galaxy Note 7, Galaxy On 5 Pro, Galaxy Xcover 4, Galaxy Xcover 4s (2019), Z (Z2, Z2 2016, Z4);

Alcatel: 1x 2019, 1x 2018, 3, LX;

Archos: Oxygen 57;

Asus: Zenfone Max (M1) ZB556KL (2018), ZenFone Live (L2) (2019);

Essential: PH-1;

Google: Pixel 3;

Google-LG: Nexus 5;

Honor: 8s (2019), Play 8 (2019);

Huawei: P10, P10 Lite, P8 Lite 2015, P8 Lite 2016, P8 Lite 2017, Y3 2017, Y3II, Y5 2019, Y5 Lite 2018, Y5 Lite 2019, Y5 Prime 2018, Y6 2017;

Komu: K60;

Lenovo: A5, Zuk Edge;

LG: G4 s, K3 2017, Nexus 4, Q6 / Q6 Plus / Q6 Alpha, Q7 / Q7 Plus / Q7 Alpha;

Mediacom: PhonePad Duo X532L, PhonePad Duo X532U;

Meizu: C9, C9 Pro, M8, M8c, V8, V8 Pro 2018;

Motorola: Moto G7 Play 2019;

NGM: You Color P509;

Nokia – Microsoft: 1 Plus, 150, 210 (2019), 216, 2.2 (2019), 3.1, 8 Sirocco, Lumia 435, X6;

Nubia: Z18 Mini;

Redmi: Go (2019);

Sharp: Aquos R2 Compact, Aquos S2; Aquos S3 mini;

Sony: Xperia (XA2, XZ1 Compact, XZ2 Compact);

Stonex: Evo;

Vodafone: Smart E9;

Wiko: Harry 2 (2018), Sunny 4 (2019);

Xiaomi: Mi 8 SE, Mi 9 SE, Mi Play, Redmi 6 (2018), Redmi 6A;

Xolo: Era 4X;

ZTE: Blade V9 Vita;

"once your smartphone is placed inside the caliper, it may not be possible to use pop-ups, pull-down menus or camera rolling or sliding"

*** All product names, logos, and brands are property of their respective owners