


TRK52N / TRK52B TREKKER



| | | | | |
|---|---------|-----------------------------|---|-------|
| 6 | Z645CR | Opening push button chromed | € | 9,00 |
| 7 | Z1782CR | Bolt | € | 12,00 |
| 8 | Z191R | Push button spring, 1 pcs. | € | 1,80 |

| | | | | |
|----|-------|-----------------------------|---|------|
| 9 | Z590R | Pin. Medium, 2 pcs. | € | 4,00 |
| 12 | Z599 | Nylon stop bag opening yarn | € | 3,00 |