



BONZY HOME
Best of New Coop Home

Assembly Instructions





CR0504A001

Your recliner comes packaged in one box.
Carefully remove all of components from the
packaging and set aside for assembly.

CAUTION


DO NOT use any sharp
objects to open plastic wrapped
components as this may result
damage to product or components .

Package Contents

			
Part A chair seat*1	Part B chair back*1	Part C chair arms*2	Part D hardware package* 1


STEP 1

Place the chair arms(C) on its seat(A) on a flat smooth surface.




STEP 2

Attach chair back(B) to chair seat(A) by aligning the metal grooves on Backrest to brackets on the mainframe as shown. Ensure the chair back(B) slides down fully over the brackets on the chair seat(A).



STEP 3

Assemble the remote control and power cord to chair seat(A).



Warnings

1. Please check if the components of the chair are all included and can be used normally as the 5th tip.
2. Assemble all components according to the instruction correctly before you connect the chair with the power.
3. Please DO NOT sit on the armrests and footrest to eliminate the risk of tipping over.
4. If the sofa is damaged or doesn't match the website product, please send clear pictures of the product and label of the carton to our service team, and we'll help you to solve the problem.
5. If the recliner doesn't work , you can try the following measures for self-checking firstly:
 - ① Check if all the cable are connected;
 - ② Check if the light of transformer is on.If the chair still doesn't work, please feed the information back to the customer service in time. We will help solve the problem for you as soon as possible.
6. If you have any questions with the product, please contact us by:

Email: anjhome2020@gmail.com (we will reply to you within 24 hours)

Phone: (314) 390- 1178 (Eastern Time 9am to 5pm on Business Days)

