


## Key Fob Power Bank

Quick Start Guide



### WHAT'S INCLUDED

- A. (1) Limitless Key Fob Power Bank
- B. (1) Carabiner Ring
- C. (1) 36" Type-C to USB Charging Cable



### COMPONENTS

- 1. Built-in Micro Cable (Output)
- 2. Carabiner Ring
- 3. Built-in Lightning Cable (Output)
- 4. Flashlight Power Button
- 5. Flashlight
- 6. Type-C Charging Port (Input/Output)
- 7. Battery Capacity Indicator Lights



### HOW TO USE

#### Getting Started

The Key Fob Power Bank will arrive with a partial charge. It is recommended to charge the battery to 100% before use.

#### Checking the Battery Level

1. Press and hold the Flashlight Power Button for 3-seconds. The 4x LED Indicator Lights will illuminate indicating how much battery is left.

See table below.

| LED INDICATOR LIGHT | CHARGE REMAINING |
|---------------------|------------------|
| ●●●●                | 0%               |
| ●●●●                | 1-25%            |
| ●●●●                | 26-50%           |
| ●●●●                | 51-75%           |
| ●●●●                | 76-100%          |

#### Recharging the Key Fob Power Bank

1. Plug the Type-C end of the included 36" USB Cable into the Type-C Port and plug the opposite end into a USB charger (not included).
2. The Indicator lights will begin to blink. Once all 4 indicator lights turn solid, the Key Fob Power Bank is fully charged.

#### Using the Flashlight

1. Press the Flashlight Power Button to turn on the Flashlight.
2. Press the Flashlight Power Button a second time to switch to the S.O.S. mode.
3. Press the Flashlight Power Button a third time to turn off the Flashlight.

#### Using the Power Bank

1. First, determine which charging connection the device is compatible with: Micro, Lightning, or Type-C.
2. To charge a device via the Type-C Charging Port, connect a compatible Type-C to Type-C cable (not included), or use one of the built-in cables. Once the device is connected, it will begin charging automatically.

#### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## LIMITLESS™

All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

**LimitlessInnovations.com**  
Support@LimitlessInnovations.com  
(855) 843-4828

Limitless Innovations, Inc.  
4800 Metalmaster Way  
McHenry, IL 60050

©Limitless Innovations, Inc.

#### 1-YEAR WARRANTY

For full Warranty details please visit:  
LimitlessInnovations.com/Warranty



Designed in USA | Made in China

### TECH SPECS

**Model:** LIM-KFPB-2PK-XXX  
**Capacity:** 2,000mAh | 7.4Wh  
**Recharging Time (From 0%):** +/- 2 Hours

**Type-C Charging Port (Input/Output):**  
5V/2A | 10W

**Built-In Cables (Output):** 5V/2A | 10W

**Flashlight:** 45LM  
**Modes:** Flashlight and S.O.S

**Total Power (Output):** 5V/2A | 10W

**Dimensions:** 4" x 1.75" x 0.6"  
**Weight:** 0.136 lb



### SAFETY INFORMATION

By using the Limitless Key Fob Power Bank, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Key Fob Power Bank. By using the Limitless Key Fob Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Key Fob Power Bank, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Key Fob Power Bank.

### SAFETY WARNINGS

- Limitless Key Fob Power Bank is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Limitless Key Fob Power Bank near a magnetic or electric field.
- Do **NOT** use the Limitless Key Fob Power Bank in direct sunlight or extreme heat for extended periods of time.
- Do **NOT** use the Limitless Key Fob Power Bank if it has been damaged and/or modified.
- Do **NOT** clean/subject the Limitless Key Fob Power Bank with harsh chemicals.
- Do **NOT** submerge the Limitless Key Fob Power Bank or its accessories in water.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate. Follow manufacture's instructions.
- Do **NOT** insert foreign objects into the openings or port of the Limitless Key Fob Power Bank.
- Do **NOT** charge the Limitless Key Fob Power Bank in high humidity conditions.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** attempt to disassemble, repair, or open the Limitless Key Fob Power Bank or its accessories in any way.
- Do **NOT** paint or apply coatings to the Limitless Key Fob Power Bank as you might affect moving parts or damage internal components.
- Do **NOT** use third party power supplies or non-approved adapters with the Limitless Key Fob Power Bank.
- Batteries should be recycled or disposed of, as per state and local guidelines.
- Do **NOT** stare directly into the flashlight.
- **AIR TRAVEL:** You may carry the Limitless Key Fob Power Bank on an airplane. Do **NOT** travel with the Key Fob Power Bank in your checked baggage.

For more information, visit:  
<https://www.faa.gov/travelers>