

LIMITLESS™

# Tassel Keychain Power Bank

Quick Start Guide



## WHAT'S INCLUDED

- (1) Tassel Keychain Power Bank
  - (1) Carabiner Ring
- (1) 36in Lightning Charging Cable
- (1) 36in Micro Charging Cable
- (1) 36in USB-A to Type-C Charging Cable

## COMPONENTS

1. USB Charging Port (Output)
2. Type-C Port (Input)
3. Power Indicator Light
4. Leather Tassels
5. Carabiner Ring



## TECH SPECS

### Model:

LIM-TSSL2-XXX

### Battery Capacity:

2,500mAh

### Recharging Time (From 0%):

±3 Hours

### Type-C Port (Input):

5V/2A

### USB Charging Port (Output):

5V/2A

### Dimensions:

4.02 in x 1.06 in x 1.06 in

### Weight:

2.68 oz (0.17 lbs)

# GETTING STARTED

The Tassel Keychain Power Bank will arrive with a partial charge. It is recommended to charge the battery to 100% upon arrival and after each use. The included Charging Cable is reversible and can recharge the power bank or another USB-chargeable device.

## Carabiner Ring

The Carabiner Ring is not on the product, it's packed directly into the box. Push the lever to attach it to a purse or keychain.



## Charging The Power Bank

Plug the Type-C Connector into the Type-C Input and a USB charger (not included). The Power Indicator Light will blink while charging and will go solid once fully charged. The Power Indicator Light will blink once the battery level reaches 5% to indicate it is time to recharge.

## Recharging A Device

Plug a USB charging cable into the USB Output then into a USB chargeable device. The device will begin to charge.

## Compatibility:

**Micro:** Select Tracfonos, Speakers, Cameras, Power Banks, & More.

**Lightning:** Compatible with iPhones, AirPods, & Most Apple Devices.

**Type-C:** Compatible with newer devices by Samsung, Microsoft, LG, Google, Huawei, select Apple iPads (2018 and newer), select Tracfonos, and More.



Scan to learn more about using the features of your Tassel Keychain Power Bank: