




LIMITLESS™

Ultimate Power Bank

Quick Start Guide




WHAT'S INCLUDED

- (1) Ultimate Power Bank
- (1) Faux Leather Storage Case
- (1) Detachable Carrying Strap
- (1) 24" Type-C to USB Cable



COMPONENTS

1. Fold-Out Phone Holder
2. Retractable AC Plug
3. Digital LCD Display
4. Built-In Type-C Cable
5. Built-In Lightning Cable
6. Built-In Micro Cable
7. Flashlight Power Button
8. Type-C Input/Output
9. (2) USB Outputs
10. Mini Flashlight



CHARGING & RECHARGING

Using the Ultimate Power Bank

Select your compatible charging method from below and connect the Ultimate Power Bank to a device. The device will automatically begin to charge.

- **Built-In Cables**
- **USB Ports**
- **Type-C Port**

Fastest Charging

For a faster charge, you can plug in your own charging cables to the USB or Type-C Charging Ports.

Recharging the Ultimate Power Bank

The device will begin to charge using one of the following methods.

- Detract the AC Plug & connect to a wall outlet.
- Plug a cable into the Type-C Charging Port and into a device.

Checking the Battery Level

Press the Power Button to show the current percentage on the screen.

COMPATIBILITY

Built-In Micro Cable

Compatible with select Samsung, Amazon Kindle, and Motorola devices as well as cameras, power banks, speakers, controllers, and more.

Built-In Type-C Cable

Compatible with most new Samsung, Google, Motorola, Microsoft, LG, and Apple iPads 2018 and newer.

Built-In Lightning Cable

Compatible with most Apple Devices.

TIP: The Limitless Ultimate Power Bank can stay in the Premium Storage Case while charging devices via the charging ports.

FLASHLIGHT

Press and hold the Power Button to turn the Flashlight on.

Single click to scan through the modes, or press and hold the Power Button to shut off the Flashlight.

PHONE HOLDER

With the Limitless Ultimate Power Bank laying on its back, pull on the inset to fold down and open the hinged Phone Holder.

Prop your device up horizontally against the raised edge of the Phone Holder and the side of the Power Bank.



TECH SPECS

Model: LIM-ULTPB-XXX

Battery Capacity: 15,000mAh | 3.7V

Recharging Time (From 0%):

Using Wall Charger: 6-8 Hours

Using Type-C Port: 3-4 Hours

*Using a 20W Wall Adapter

AC Input: 110-240VAC, 50/60Hz, 0.5A

Type-C Input/Output: PD 20W

USB Outputs: QC 22.5W

Built-In Cables Output: 5V/3A (Max)

Temperature Range (Operation):

32°-113°F (0°-45°C)

Flashlight: 25 Lumens

Dimensions: 5.79" x 3.032" x 1.26"

Weight: 12.34 oz (0.77 lb)

SAFETY INFORMATION

By using the Limitless Ultimate Power Bank, you hereby agree that Limitless Innovations, Inc., an Illinois corporation and its affiliates ("Limitless") shall have no liability for any losses associated with property damage, personal injury or loss of life that are incurred by you or by any third party in connection with or relating in any manner whatsoever to your use of the Limitless Ultimate Power Bank. By using the Limitless Ultimate Power Bank, you hereby agree at all times to comply fully with all safety warnings, operating instructions and general safety information in this user manual. By using the Limitless Ultimate Power Bank, you further agree to hold harmless Limitless, (and Limitless' officers, directors, shareholders and employees) in connection with any losses sustained by you (including, without limitation, losses arising in whole or in part from property damage, personal injury or loss of life) relating in any manner whatsoever to your use of the Limitless Ultimate Power Bank.

WARNING

- Limitless Ultimate Power Bank is **NOT** a toy and should be kept away from children.
- Do **NOT** use the Limitless Ultimate Power Bank near a magnetic or electric field.
- Do **NOT** use the Limitless Ultimate Power Bank in direct sunlight or extreme heat for extended periods of time.
- Do **NOT** use the Limitless Ultimate Power Bank if it has been damaged and/or modified.
- Do **NOT** subject the Limitless Ultimate Power Bank to harsh chemicals.
- Do **NOT** submerge the Limitless Ultimate Power Bank or its accessories in water.
- **CAUTION:** Risk of fire and burns. Do **NOT** open, crush, heat above 140° F (60° C) or incinerate. Follow manufacture's instructions.
- Do **NOT** insert any foreign objects into the openings or port of the Limitless Ultimate Power Bank.

- Do **NOT** charge the Limitless Ultimate Power Bank in high humidity conditions.
- Do **NOT** attempt to replace the battery as it is a non-serviceable part.
- Do **NOT** attempt to disassemble, repair, or open the Limitless Ultimate Power Bank or its accessories in any way.
- Do **NOT** paint or apply coatings to the Limitless Ultimate Power Bank as you might affect moving parts or damage internal components.
- Do **NOT** use third party power supplies or non-approved adapters with the Limitless Ultimate Power Bank.
- Batteries should be recycled or disposed of, as per state and local guidelines.

SCAN TO LEARN MORE:



LIMITLESS™

Designed in USA. Made in China. All rights reserved. Limitless™ is a trademark of Limitless Innovations, Inc. Design and specifications subject to change without notice. Products may vary from images shown. Accessories sold separately.

LimitlessInnovations.com

Support@LimitlessInnovations.com
(855) 843-4828

Limitless Innovations, Inc.
4800 Metalmaster Way
McHenry, IL 60050

© Limitless Innovations, Inc.



@LimitlessInnovations



/LimitlessInnov



/LimitlessInnov



/LimitlessInnov



Limitless Innovations