


KISTLER SERIES 2 REEL KS2-R181

100



Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
C001	FRAME	C038	LEVEL WIND PIN	C070	DRAG 'A' WASHER
C002	TAPPING SCREW	C039	PIPE	C071	DRAG DISC WASHER
C003	STOPPER PLATE	C040	WORM SHAFT	C072	DRAG WASHER
C004	STOPPER	C041	BALL BEARING	C073	SLEEVE
C005	SPRING	C042	WORM GEAR	C074	ONE WAY CLUTCH
C006	STOPPER LEVER	C043	E-RING	C075	GEAR SIDE COVER
C007	TAPPING SCREW	C044	PILLAR	C076	DECO CAP
C008	TAPPING SCREW	C045	TAPPING SCREW	C077	TAPPING SCREW
C009	TAPPING SCREW	C046	BALL BEARING	C078	WASHER
C010	BALL BEARING	C047	E-RING	C079	DRAG CLICK HOLDER
C011	CONTROL DIAL	C048	BEARING PLATE	C080	DRAG CLICK SPRING
C012	CLICK SPING	C049	CRANK SHAFT	C081	SPRING WASHER
C013	PALM SIDE COVER	C050	O.S GEAR	C082	WASHER
C016	SLIDE 'B'	C051	RATCHER	C083	STAR DRAG
C017	SLIDE 'A'	C052	WASHER	C084	HANDLE WASHER
C018	SPRING	C053	DRIVE GEAR	C085	G/S/COVER SCREW
C019	SPOOL COVER	C054	KICK LEVER HOLDER	C086	BALL BEARING
C020	BRAKE RING ASS'Y	C055	KICK LEVER	C087	HEX-RING
C022	WASHER	C056	SPRING	C088	CLICKER
C023	HEX-RING	C057	TAPPING SCREW	C089	WASHER
C024	BRAKE SHOE ASS'Y	C058	THUMB BAR	C090	WASHER
C025	SPOOL ASS'Y(1B/B)	C059	TAPPING SCREW	C091	TENSION KNOB
C026	BEARING HOLDER	C060	CLUTCH CAM	C092	HANDLE ASS'Y
C029	TAPPING SCREW	C061	SPRING	C093	BALL BEARING(2 B/B)
C030	LINE GUIDE	C062	CLUTCH LINK	C094	HANDLE KNOB
C031	TAPPING SCREW	C063	LINK SCREW	C095	BUSHING (2 BUSHING)
C032	E-RING	C064	E-RING	C096	SCREW
C033	BUSH	C065	CLUTCH	C097	HANDLE KNOB CAP
C034	LEVEL WIND	C066	COIL SPRING	C098	HANDLE NUT
C035	HOOD	C067	PINION GEAR	C099	HANDLE NUT RETAUNER
C036	LEVEL WIND NUT	C068	DRAG "B" WASHER	C100	SCREW
C037	WASHER	C069	DRAG "D" WASHER		