


KISTLER SERIES 1 REEL KS1-R173



Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
C001	FRAME	C038	LEVEL WIND PIN	C072	DRAG WASHER
C002	TAPPING SCREW	C039	PIPE	C073	SLEEVE
C003	STOPPER PLATE	C040	WORM SHAFT	C074	ONE WAY CLUTCH
C004	STOPPER	C041	BALL BEARING	C075	GEAR SIDE COVER
C005	SPRING	C042	WORM GEAR	C076	DECO CAP
C006	STOPPER LEVER	C043	E-RING	C077	TAPPING SCREW
C007	TAPPING SCREW	C044	PILLAR	C078	WASHER
C008	TAPPING SCREW	C045	TAPPING SCREW	C079	DRAG CLICK HOLDER
C009	TAPPING SCREW	C046	BALL BEARING	C080	DRAG CLICK SPRING
C010	BALL BEARING	C047	E-RING	C081	SPRING WASHER
C011	CONTROL DIAL	C048	BEARING PLATE	C082	WASHER
C012	CLICK SPING	C049	CRANK SHAFT	C083	STAR DRAG
C013	PALM SIDE COVER	C050	O.S GEAR	C084	HANDLE WASHER
C016	SLIDE 'B'	C051	RATCHER	C085	G/S/COVER SCREW
C017	SLIDE 'A'	C052	WASHER	C086	BALL BEARING
C018	SPRING	C053	DRIVE GEAR	C087	HEX-RING
C019	SPOOL COVER	C054	KICK LEVER HOLDER	C088	CLICKER
C020	BRAKE RING ASS'Y	C055	KICK LEVER	C089	WASHER
C022	WASHER	C056	SPRING	C090	WASHER
C023	HEX-RING	C057	TAPPING SCREW	C091	TENSION KNOB
C024	BRAKE SHOE ASS'Y	C058	THUMB BAR	C092	HANDLE ASS'Y
C025	SPOOL ASS'Y(1B/B)	C059	TAPPING SCREW	C093	BALL BEARING(2B/B)
C026	BEARING HOLDER	C060	CLUTCH CAM	C094	HANDLE KNOB
C027	DRAG CLICKER	C061	SPRING	C095	BALL BEARING(2B/B)
C028	SPRING	C062	CLUTCH LINK	C096	SCREW
C029	TAPPING SCREW	C063	LINK SCREW	C097	HANDLE KNOB CAP
C030	LINE GUIDE	C064	E-RING	C098	HANDLE NUT
C031	TAPPING SCREW	C065	CLUTCH	C099	HANDLE NUT CAP
C032	E-RING	C066	COIL SPRING	C100	SCREW
C033	BUSH	C067	PINION GEAR	C101	CLICKER
C034	LEVEL WIND	C068	DRAG "B" WASHER	C102	LINE DIAL
C035	HOOD	C069	DRAG "D" WASHER	C105	HANDLE NUT HOLDER
C036	LEVEL WIND NUT	C070	DRAG 'A' WASHER	C106	SCREW
C037	WASHER	C071	DRAG DISC WASHER		