

The **MTNTK** BlowHole

Polaris Ranger 900 & 1000 Installation Instructions



Disclaimer: Never attempt to adjust or run engine with fan on. Do not stick your fingers into the fan housing as it will cut or dismember. Mountain Tek Performance is not responsible for damages incurred by using this product or improper installation.

208.652.0122

MTNTKperformance.com



2. Loosen the clamp on the clutch exhaust hose.



4. Now install Blow Hole onto clutch housing as shown. Tighten clamp.



1. Lift rear bed exposing the engine.



3. Separate the exhaust hose from the clutch housing.



5. Then install exhaust hose onto Blow Hole assembly. Tighten clamp.



6. Route wire along brake light power cable.
Unplug tail light connector.



7. Plug in Blow Hole in line. The Blow Hole will run anytime the key is in the "on" position and for a brief 15 second time frame that the ECU keeps the chassis relay powered up after shutdown.