



Handlebar-attachable carry bag




Parts

- a | Bicycle Bag
- b | Carry Bag
- c | Strap attachment
- d | Shoulder strap

Depending on bike size and type, seat and handlebars may protrude from bicycle bag. With some bikes, it may be necessary to remove both wheels. **Warning** When carrying bag on bike, ensure it does not interfere with function of gear and brake cables.

Instructions



Open and spread out bicycle bag. Find lengthways centreline (fig. 1).



Remove front wheel and stand bike on centreline (fig. 2).



Zip up rear end of bag (fig. 3).



Zip up front end of bag (fig. 4).



Place front wheel in wheel sleeve (fig. 5).



Close velcro along top to seal bag (fig. 6).



Attach strap under seat, around seatpost.

Attach strap under handlebars, around stem.

Attach shoulder strap to seatpost and stem (fig. 7).



To carry bag on bike, fold neatly, place in carry bag. Attach tightly to handlebars with strap attachments (fig. 8).

Limited Warranty

Ibera warrants this product for normal usage against workmanship, and material defects to the original purchaser for one year from purchase date. Products purchased online are not covered by this warranty unless purchased from an authorised Ibera online store. 1. User assumes all risk of personal injury, damage to or failure of the product when it is used in jumping, acrobatics or similar activities. 2. Warranty does not cover any incidental or consequential damages, such as personal injury or other losses due to accident, neglect, misuse, abuse, modification, normal wear and tear, improper care and cleaning, or failure to follow included instructions.

See other Ibera products at www.ibera.info

Ibera Co. Ltd.
Specifications subject to change without notice. Ibera is a trademark of Ibera Co. Ltd. All other trademarks are property of their respective owners. Copyright 2016 Ibera Co. Ltd. Made in Taiwan. Artwork: 4-2016.