

We care about the Environment

By refraining from inserting a full printed manual with our Argon Audio products we save more than 20 tons of paper each year. You can find a full User Manual in PDF format for this product on: www.argonaudio.com
See back side of this insert for Quick start guide

Safety

Safety Instructions



Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.

- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.

- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.
- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.



If there is a Lightning flash with an arrow head on the product, it's intended to alert the User of the presence of un-insulated "dangerous voltage" within the product, that might be of sufficient magnitude to constitute a risk of electric shock to persons.



If there is an Exclamation point on the product, it's intended to alert the User that there is important operating and maintenance [servicing] information in the User manual.



If there is a double rectangular symbol on the product, it means that the product is double insulated. Earth connection is not required.

Quick start

1. Connect the speakers using the included speaker cable.
2. Connect the power cord into an electric outlet and into the back of the left speaker [which has the amplifier]. The LED light on the loudspeaker will turn on.
3. To pair your Bluetooth device, turn on the speakers and press and hold 'BT' on your remote for about 3 seconds, until the LED starts blinking. Your speakers are now in pairing mode. Activate Bluetooth on your playback device and scan for devices. Your speaker will show up as "Argon Audio FENRIS". Press "pair" and you're connected. The LED light on the speaker will change to solid blue. You're now ready to start listening to music!
4. Besides Bluetooth, your FENRIS speakers have four more inputs: TV ARC, D1, AUX and Phono. FENRIS will automatically switch between the inputs, but you can also use the included remote control to select your wished input.
5. When using the TV ARC input, you might need to set the digital sound output on your TV to PCM. Consult your TV manual to see how.
6. When connecting a turntable to the Phono input on the FENRIS speaker, remember to also connect the ground wire from the turntable to the metal GND screw [if applicable].
7. If you have an active subwoofer, connect it to the FENRIS speaker's Pre-out, using an RCA cable and then connect the cable to your subwoofer.

8. We recommend a running-in time of your FENRIS speakers of approximately 15-20 hours at normal listening level before you decide on the final positioning of the speakers.

Basic operating

1. When the FENRIS speakers receive input from any connected source [except Phono], they will automatically power on [if powered off] and switch to the right input. This is called Auto Power Up. Note: this will not happen if the speakers are already powered on and playing from another source.
2. You can disable Auto Power Up [APU] if needed: simply press and hold the power button on remote control for 5 seconds while the speakers are on. The speakers will now power off with APU disabled. This will also disable automatic power off, meaning you need to turn off your speakers manually.
3. To enable APU again, simply press and hold the power button for 5 seconds again when the speaker is powered off.
4. You can always press and hold the 'BT' button to reset all Bluetooth connections. Please note that Bluetooth pairing is only available when the Bluetooth-input is selected.
5. To enable dimming of the LED on the front of the speaker, power on the speaker and hold the D1 button on the remote for 5 seconds. The LED will now turn off after 5 seconds after switching inputs. To disable again, press and hold D1 for 5 seconds again.