

## We care about the Environment

By refraining from inserting a full printed manual with our Argon Audio products we save more than 20 tons of paper each year.

See back side of this insert for Quick start guide

## Safety

### Safety Instructions



- Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.

- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.
- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.



If there is a Lightning flash with an arrow head on the product, it's intended to alert the User of the presence of un-insulated "dangerous voltage" within the product, that might be of sufficient magnitude to constitute a risk of electric shock to persons.



If there is an Exclamation point on the product, it's intended to alert the User that there is important operating and maintenance (servicing) information in the User manual.

## Quick start

1. Connect the speakers using the supplied speaker cable.
2. Connect the power cord into an electric outlet and into the back of the left speaker (which has the amplifier). The LED light on the loudspeaker will turn on.
3. To pair your Bluetooth device, turn on the speakers and press and hold "PAIRING" on your remote for about 3 seconds, until the LED starts blinking. Your speakers are now in pairing mode. Activate Bluetooth on your playback device and scan for devices. Your speaker will show up as "ARGON FORTE". Press "pair" and you are connected. The LED light on the speaker will change to solid blue. You're now ready to start listening to music!
4. Besides Bluetooth, your Forte speakers have four more inputs: Optical1, Optical2, AUX and Phono. Use the included remote control to select your wished input.
5. When connecting a turntable to the Phono input on the Forte speaker, remember to also connect the ground wire from the turntable, to the metal GND screw.
6. If you have an active subwoofer, connect it to the Forte speaker's SUB OUTPUT, using a RCA cable and then connect the cable to Your Subwoofer.
7. Your Argon Forte speakers support most Samsung, Sony and LG remote functions for "Volume +/-" and "Mute" using IR remotes only.
8. We recommend a running-in time of your Forte speakers of approximately 15-20 hours at normal listening level before you decide on the final positioning of the speakers. During the running-in time the drive units will settle in and perform as intended.
9. For optimal sound performance, the best listening position is at ear level with the speakers placed not too far from a wall.

## Basic operating

1. When the Forte speakers receive input from any connected source (except phono), they will automatically power on (if powered off) and switch to the right input. This is called Auto Power Up. Note: this will not happen if the speakers are already powered on and playing from another source.
2. You can power the speakers off with Auto Power Up (APU) disabled if needed: simply press and hold the power button on remote control for 5 seconds when powering off. The speakers will now power off with APU disabled.
3. The next time you turn on the speakers again, APU will be enabled again.
4. You can always press and hold the "PAIRING" button to reset all Bluetooth connections.