

### **1. CHARGING INSTRUCTION**

Please fully charge the case and ear buds before first time use. The different numbers of LEDs on the bottom of the charging case flashing will show the different charge level of the case; see the chart below for details. When the charging case is fully charged, all four lights turn on.

Power	LED light
<25%	The first light is flashing
25-50%	The first light is on, and the second light is blinking
50-75%	The first two light is on, and the third light is blinking
75-99%	The first three lights are on, the 4th light is blinking
100%	All four lights are on

#### 2. POWER ON/PAIRING MODE

Open the charging case while the earbuds are still in the case to initiate pairing mode. Enter Bluetooth

# **IE20 QUICK START**

settings on your device and select *Argon Audio IE20* to start pairing. If the pairing was successful; you will hear the "connected" voice prompt in the ear buds.

To enter pairing mode manually, place both left and right earbuds into the charging case, keeping the case cover open. Press and hold the charging case button for 5 seconds. The four LEDs will flash alternately in pairs before emitting constant light for 3 seconds. This indicates that the earphones have entered Bluetooth searching and pairing mode. If there is no connection in pairing mode for 5 minutes, the earbuds will automatically power off.





## **IE20 QUICK START**

### **3. MUSIC AND PHONE CONTROLS**

Play/Pause/Reject/End calls	Press the L/R ear bud button 2		
	times		
Answer a call	Press the L/R ear bud button once		
Answer a call	Press the L/R ear bud button once		
Volume up	Press the Right ear bud button once		
	-		
Volume down	Press the Left ear bud button once		
volume down	Fless the Left ear but button once		
Previous song	Press and hold the Left ear bud		
	button for 1.5 seconds		
Next song	Dragg and hold the Dight our hud		
Next song	Press and hold the Right ear bud		
	button for 1.5 seconds		
Voice assistant	Press the L/R ear bud button 3		
	times		
	lines		
Power off	Dut I /D soulouds into the second stars		
Power Off	Put L/R earbuds into the case, close		
	the charging case		
ANC on/ambient mode/default	Press and hold R/L button 2		
mode	seconds to switch the Modes		
mode	seconds to switch the Modes		



### **4. RESTORE FACTORY SETTINGS**

Remove the earphone device listing from the Bluetooth settings on your phone. Place the earphones into the charging case.

Press and hold the charging case button for 10 seconds with the case cover open. The 4 light indicators on the charging case will start flashing, before emitting constant light for 3 seconds.