

We care about the Environment

By refraining from inserting a full printed manual with our Argon Audio products we save more than 20 tons of paper each year. You can find a full User Manual in PDF format for this product on; www.argonaudio.com

See back side of this insert for Quick start guide

Safety

Safety Instructions



- Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.

- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.
- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.



If there is a Lightning flash with an arrow head on the product, it's intended to alert the User of the presence of un-insulated "dangerous voltage" within the product, that might be of sufficient magnitude to constitute a risk of electric shock to persons.



If there is an Exclamation point on the product, it's intended to alert the User that there is important operating and maintenance (servicing) information in the User manual.

Radio1,2and3 Quick start

Quick start

Start up

1. Extend the Antenna
2. Plug the Power supply into an electric outlet and into the back of the Radio.
3. The Radio will start searching for DAB stations automatically. This may take a few minutes and the progress will be shown in the display.
4. Once finished searching, the Radio will start playing the first found station.

Basic Operating

1. Stations can be chosen by turning the "Tuning/Select" knob.
2. Once the prefer station is found press the "Tuning/Select" knob and the chosen station will start playing.
3. To store a station on one of the 1-6 preset buttons, press and hold the wished preset button for 3 sec., while playing the station that you want to store.
4. When stored, the display will show "Preset X saved"
5. To change between the Modes DAB, FM, AUX and Bluetooth (if your Radio has this function), press the "Source" button repeatedly until you reach the preferred Mode.
6. To tune stations in FM Mode press and hold the "Autotune" button for 3 sec. and the Radio will scan to the next available station. You can store FM stations like mentioned in point 3.
7. Bluetooth (**only if your product have Bluetooth function**). To pair and connect to a Bluetooth

player device (Tablet, Laptop, Mobile Phone etc), press the Bluetooth symbol button on the Radio and the Radio will go into Bluetooth mode. Activate Bluetooth on your Player device and let it scan for Bluetooth devices. When the Argon Audio Radio is found, paired and connect via your Player, you can start play back immediately.

For more Bluetooth operating instructions, look in the full User manual at www.argonaudio.com

Other Operating functions

Inactive standby

The Radio is default set to turn off automatically after 120 minutes To change this feature:

1. Press and hold the **Display** button for 3-5 seconds until the Menu appears.
2. Then turn the **Tuning/Select** knob until it shows "System" in the display and select this with a press on the **Tuning/Select** knob.
3. Turn the **Tuning/Select** knob until "Inactive Standby" appears in the display then select this by pressing the **Tuning/Select** knob.
4. Then by turning the **Tuning /Select** knob - select " Timeout: 2,4,5,6 hours or Off". Activate the selected time by pressing the **Tuning/Select** knob.
5. Exit the setup menu by repeatedly pressing the **Display** button.

You can find a full User Manual in PDF format for this product at; www.argonaudio.com