

We care about the Environment

By refraining from inserting a full printed manual with our Argon Audio products we save more than 20 tons of paper each year.

See back side of this insert for Quick start guide

Safety

Safety Instructions



- Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.
- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.

- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.
- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.



If there is a Lightning flash with an arrow head on the product, it's intended to alert the User of the presence of un-insulated "dangerous voltage" within the product, that might be of sufficient magnitude to constitute a risk of electric shock to persons.



If there is an Exclamation point on the product, it's intended to alert the User that there is important operating and maintenance (servicing) information in the User manual.



If there is a double rectangular symbol on the product, it means that the product is double insulated. Earth connection is not required.


Quick start

1. Connect the Power cord into an electric outlet and into the back of the Amplifier.
2. Connect your speakers to the Amplifier using normal speaker cable.
3. Connect your source player (tablet, laptop, mobile phone, CD player, TV) to an input on the amplifier, using the input connection that fits your source device best.
4. The SA1 has a pre out, enabling you to connect an active subwoofer or a power amplifier.

Basic Operating

1. Power ON from standby is done either by pressing the Power button on the SA1 or the Power button on the Remote.
2. Entering Stand-by is done by either a short press on the Power button on the SA1 or by pressing the Power button on the remote
3. Input source is automatically sensed. Once a music source is playing the SA1 will automatically switch to the latest chosen input source. You can also manually choose your input source using the remote control.
4. BT pairing is done by choosing the BT input source on the SA1. The SA1 will then automatically go into pairing mode. Use your phone, Laptop or tablet to pair and connect.

Overview of inputs



1. Ground
2. USB power for Chromecast
3. Phono (MM) for turntable only
4. Line in for analogue sources (AUX)
5. Optical 1 (D1), optimized for TV input
6. Optical 2 (D2), optimized for HiFi listening
7. Pre out for pre-amplifier or subwoofer
8. Speaker right
9. Speaker left
10. Power