

We care about the Environment

By refraining from inserting a full printed manual with our Argon Audio products we save more than 20 tons of paper each year. You can find a full User Manual in PDF format for this product on; www.argonaudio.com

See back side of this insert for Quick start guide

Safety Instructions



- Unplug this product from the wall outlet before cleaning. Do not use this product near water or moisture. Do not spill liquids on the product. Clean only with a dry cloth.
- Place the unit on a solid surface.
- Do not put it in a closed bookcase or a cabinet that may keep air from flowing through its ventilation openings.
- Do not install near any heat sources, such as radiators, heat registers, stoves or other appliances that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs and the point where they exit from the product.

- During Lightning storms, unplug the product from the power source or if unused for long periods of time. This will prevent lightning and power-line surge damage to the product.
- Do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please contact the manufacturer to be referred to an authorized service center near you.
- Do not overload wall outlets, extension cords, or integral power circuits as this can result in a risk of fire or electric shock.
- Never push any object through the product openings, as this can result in fire, electric shock or damage.
- Use proper power sources. Plug the product into a proper power source, as described in the operating instructions or as marked on the product.



If there is a Lightning flash with an arrow head on the product, it's intended to alert the User of the presence of un-insulated "dangerous voltage" within the product, that might be of sufficient magnitude to constitute a risk of electric shock to persons.



If there is an Exclamation point on the product, it's intended to alert the User that there is important operating and maintenance (servicing) information in the User manual.

Quick start

1. Make sure your Wi-Fi network is available.
2. Plug the antenna cable into the Stream 3 MK2.
3. Connect the Stream 3 MK2 to your device, using the optical or RCA output.
4. Plug the power supply into an electric outlet and into the back of the Stream 3 MK2.
5. Once connected, the Stream 3 MK2 will start up automatically and take you through a setup guide.
6. In the guide, choose your wished setting by pressing the “arrow” buttons on the remote and confirm your choices by pressing the “Select” button.
7. Final step in the guide is entering the Wi-Fi code; use the “arrow” buttons to choose the letters/numbers of the password, confirm each letter/number by pressing the “Select” button. Once you have finished entering the password, press the “arrow” buttons until it reaches the “OK” area in the display on the right-hand side and press the “Select” button to confirm. The Stream 3 MK2 will now connect to your network.

Basic Operating

1. Use the “Mode” button to change between the modes: Internet Radio, Music Player, DAB, FM, AUX, Spotify and Bluetooth
2. In **Internet Radio** mode press the “Menu” button to recall Internet Radio Menu. To see station lists and stations, choose “Station List” in the Menu and press the “Select” button to select.
3. If you want to see what stations area available, select “Stations” and press the “Select” button. You now have the choice to search and list stations by several criteria’s. Once you make a choice remember to use the “Select” button to confirm.
4. For **DAB**, first time you choose DAB mode, the Stream3 will automatically start a search for available DAB stations.
5. DAB Stations can be chosen by pressing the “Arrow” buttons.

6. Once the prefer station is found press the “Select” button and the chosen station will start playing.
7. Automatic station search in **FM** mode is done by pressing and holding the “Autotune” button.
8. To store a station in DAB or FM mode on one of the preset buttons, press and hold the wished preset button for 3 sec., while playing the station that you want to store. When stored, the display will show “Preset stored”.
9. In **Bluetooth** mode, activate Bluetooth on your phone, tablet or laptop, search for “new device”, add your Stream 3 MK2, pair and the Stream 3 MK2 is connected and ready for playback.



Spotify Connect

Use your phone, tablet, or computer as a remote control for Spotify. Go to [spotify.com/connect](https://www.spotify.com/connect) to learn how.

The Spotify Software is subject to third party licenses found here: <https://www.spotify.com/connect/third-party-licenses>

You can find a full user manual in PDF format for this product on www.argonaudio.com