


公司品牌：Cubitt	备注： 第一版，
产品型号：Cubitt Power Go	
设计项目：说明书	
文件名称：Cubitt_Bastion1_Cubitt Power Go_说明书_折页_01	
说明书尺寸：60mm X 90mm（展开尺寸：300mm X 90mm）	
工艺说明：105g铜板纸，单色正反面印刷，折页（折扇形）。	
制作版本：01	



正面

Package including • 1 pcs* Cubitt Power PRO Gen2 wireless speaker • 1 pcs* Product manual • 1 pcs* Type-C USB cable TWS Connection 1. Turn on both speakers. 2. Press and hold the Play/Pause-button on one of the speakers for about 2 seconds until you hear a "beep" sound. The default is the primary speaker that you operated the Play/Pause-button of this speaker for pairing initially. 3. Release Play/Pause-button. It can take a few more seconds before speakers connect to each other. Check the indicator lights to distinguish L/R channel: the white light on one speaker is flashing white for every 3 seconds that should be the left channel (the primary speaker); the white light on the other speaker is solid white that should be the right channel. 4. Go into the Bluetooth menu on your smartphone and pair the speakers with your phone by selecting the speaker model number. (It will only display 1 number which is both combined into one). TWS Disconnection 1. Press and hold the Play/Pause-button on one of the speakers for about 2 seconds until you hear a "beep" sound.	Fault and Maintenance First fault: connection failed. Solution: 1. Please check whether the multifunction indicator light flashes white. Please power on your speakers if the light isn't on. Please charge the speaker if the light is still not on. 2. Please turn off the other Bluetooth devices, if there are many Bluetooth devices surrounding. This may result in search difficulties. 3. Restart wireless speaker on devices for Bluetooth search function. Second problem: the music player appears sound breaks. Solution: 1. View the distance between the player and the speaker has not been exceeded effective Bluetooth connection distance 8-12 meters. 2. Ensure there is not any obstacle between the play device and speakers. 3. Check the playback device or whether the speaker is in a low power state.	Notes before use This product is designed with full attention for safety performance. To ensure safe operation, please follow the following rules: 1. Place the speakers in a stable position avoid fall and cause damage or personal injury. 2. Do not drop, disassemble, open, crush, bend, puncture, burn speaker. 3. Do not close to any heat source (such as radiators, heating equipment, stoves, or other heat-generating equipment) where the use of speakers. 4. Please send professional maintenance staff to repair for any reason damage. 5. Before wiping with a dry cloth to clean the speakers, set the power switch to the off position and unplug the power cord from the power outlet. 6. Health considerations, please adjust the sound to a suitable level. FCC Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference. 2. This device must accept any interference received, including interference that may cause undesired operation. Warning Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Note This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.	Troubleshooting The speaker does not turn on ? Recharge your speaker. The speaker does not turn off or does not respond? Reset your speaker. hold the power button for 8 seconds to automatically reset the speaker and turn it off. There is no sound? Adjust the volume. Make sure that your Bluetooth device is within range. Ensure there are no obstacles in the way that can block/disturb the signal. Check via the device's Bluetooth connection if the speaker is connected with the device. There is poor sound quality? Move the device closer to the speaker or try removing obstacles between them. Cannot connect the device with the speaker? Disconnect other connected devices and then try again. You can force a disconnection by moving out of Bluetooth range (10 m). In order to avoid harming the product performance, please do charge your device each 3 months at least.
---	--	---	--	--

反面

公司品牌：Cubitt	备注： 第一版，
产品型号：Cubitt Power Go	
设计项目：说明书	
文件名称：Cubitt_Bastion1_Cubitt Power Go_说明书_折页_01	
说明书尺寸：60mm X 90mm（展开尺寸：300mm X 90mm）	
工艺说明：105g铜板纸，单色正反面印刷，折页（折扇形）。	
制作版本：01	



正面

Fallo y Mantenimiento Primer fallo: la conexión falló. Solución: Compruebe si la luz multifunción parpadea en blanco. Encienda sus parlantes si la luz no está encendida. Cargue el altavoz si la luz aún no está encendida. Apague los demás dispositivos Bluetooth si hay muchos dispositivos Bluetooth conectados alrededor. Esto puede resultar en dificultades de búsqueda. Reinicie el altavoz inalámbrico en los dispositivos para la función de búsqueda de Bluetooth. Segundo fallo: el reproductor de música aparece sonido se rompe. Solución: Verifique que no se haya excedido la distancia entre el reproductor y el altavoz. Distancia de conexión Bluetooth efectiva de 8 a 12 metros. Asegúrese de que no haya ningún obstáculo entre el dispositivo de reproducción y los altavoces. Verifique el dispositivo de reproducción o si el altavoz está en un estado de bajo consumo.	Antes de usar: Este producto está diseñado prestando total atención al rendimiento de seguridad. Para garantizar una operación segura, siga las siguientes reglas: - Coloque los parlantes en una posición estable para evitar caídas y causar daños o lesiones personales. - No deje caer, desmonte, abra, aplaste, doble, perforo ni queme el altavoz. - No acerque los parlantes a ninguna fuente de calor (como radiadores, equipos de calefacción, estufas u otros equipos que generen calor). - Envíe a personal de mantenimiento profesional para reparar cualquier daños. - Antes de limpiar los altavoces con un paño seco, coloque el interruptor de encendido en la posición de apagado y desenchufe el cable de alimentación del tomacorriente. - Consideraciones de salud: ajuste el sonido a un nivel adecuado. Declaración FCC Este dispositivo cumple con la Parte 15 de las normas de la FCC. La operación está sujeta a las dos condiciones siguientes: - Este dispositivo no puede causar interferencias dañinas. - Este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan provocar un funcionamiento no deseado. Advertencia Los cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.	Nota Este equipo ha sido probado y cumple con los límites para un dispositivo digital Clase B, de conformidad con la Parte 15 de las normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera usos y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas en la recepción de radio o televisión, lo cual se puede determinar encendiendo y apagando el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas: - Reoriente o reubique la antena receptora. - Incremente la separación entre el equipo y el receptor. - Conecte el equipo a una toma de corriente de un circuito diferente al que está conectado el receptor. - Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda. Declaración FCC Exposición a la radiación: Este equipo cumple con los límites de exposición a la radiación de la FCC establecidos para un entorno no controlado. Este equipo debe instalarse y operarse con una distancia mínima de 20 cm entre el radiador y su cuerpo.	Solución de problemas ¿El altavoz no enciende? Recargue su altavoz. ¿El altavoz no se apaga o no responde? Reinicie su altavoz. Mantenga presionado el botón de encendido durante 8 segundos para restablecer automáticamente el altavoz y apagarlo. ¿No hay sonido? Ajusta el volumen. Asegúrese de que su dispositivo Bluetooth esté dentro del alcance. Asegúrese de que no haya obstáculos en el camino que puedan bloquear/perturbar la señal. Verifique a través de la conexión Bluetooth del dispositivo si el altavoz está conectado con el dispositivo. ¿Hay mala calidad de sonido? Acerque el dispositivo al altavoz o intente eliminar obstáculos entre ellos. ¿No se puede conectar el dispositivo con el altavoz? Desconecte otros dispositivos conectados y vuelva a intentarlo. Puede forzar una desconexión alejándose del alcance de Bluetooth (10 m). Para evitar dañar el rendimiento del producto, cargue su dispositivo al menos cada 3 meses.	Cubitt cubittofficial.com @cubitt
--	--	---	--	--

反面