
STILK SIDE TABLE

Assembly guide



STEP 1

Insert the brass rod in one of the holes depending on the desired height. Insert the table top on the leg. To change the height of the table, lift the table top and move the brass rod.



STEP 2

The side table can be moved around by lifting at the top of the leg.