



SAFE USE OF EARPHONES

To prevent possible hearing damage, please do not listen at high volume levels for long periods.

WHEN DRIVING

DO NOT use the earphones.

Do not use the earphones in unsafe situations, such as driving, crossing the street or engage in any activity which require your full attention.

NOTE

DO NOT leave the earphones near magnets. Under the influence in other magnetic field the sensitivity of the speaker can drop down!

DO NOT leave th earphones in wet conditions to prevent rust & damage.

DO NOT disassemble. Disassembling the earphones will not be covered by warranty.

DO NOT use outside in very cold weather.

HEARING SAFETY INFO

In order to avoid hearing damage, before connecting the headphones, reduce the volume of the music player, when you place the headphones into your ears gradually increase the volume.

SPECIFICATIONS

Weight: 20g
 Plug Type: 3.5mm
 Frequency: 20-20000 Hz
 Impedance: 24Ω
 Sensitivity: 115dB/mW
 Built-in Mic

OMEODT EADTIDS EIT



BUTTON FUNCTIONS



Press and Release the center button to Answer/End Calls
Press, Hold and Release the button to reject Calls
Press and Hold for Voice Assistant
Other functions: Play/Pause, Previous/Next, Answer/End Calls, Voice Assistant





