


SPORTBUDS

USER MANUAL (EN)



Compatible with Android & iOS



- Multifunction button

- Indicator Light
- Built-in Mic
- Power Button
- Charging Port
- Indicator lamp of the charging box battery capacity
- Charging Case

NBUTTONS

Press & hold shortly button (3) for and briefly press 4 for F Long press button 1 and 2 to 1 Short press button (1) or (2) to (Press twice button 4 to Activate iri or press three times (for other ' Press shortly button (3) to I volume and 4 to Press twice button 1/2 to last number

When you remove the earbuds from the case the will automatically turn on & pair (If the headphones r automatically, please press button 🕦 or ② twice). Turn on the Bluetooth device to which you will connect the earbuds, find the name of the earbuds, connect them and when you hear the sound command "Connected" the two devices are paired. Once you have connected the earbuds to your device pairing will happen automatically when you use it again.

1. Place the left and right earbud in the charging case and press button (to start or stop charging. When fully charged LED light stops.

2. Use the provided Micro USB cable to charge the case. When fully charged the LED light will stop.

Charge at least once a month the earbuds if you don't use them for a long period of time so it can protect the battery life. When the earbuds are on but not paired up to 5 minutes they will automatically turn off in order to protect the battery life.

If the device does not turn on or disconnects, press & hold the power button for 8-10 seconds to restart & reset.

- 1. Wireless version: 5.0
- 2. Working distance: 10m
- 3. Transmitting power: Class 2
- 4. Frequency band: 2.402 -2.480 GHz
 - 5. Speaker: Ø14mm
 - 6. Impedance: 32
- 7. Lithium rechargeable battery: 40mAh * 2
- Rechargeable lithium battery: 300mAh
 - 8. Disposable time: 4 hours
 - 9. Case use time: 14 hours
 - 10. Charging time: 1 hour