



**GP296**  
**Pro Command**  
**Wireless Gaming Headset**  
**USER'S MANUAL**

## **EN**

### **PRO Command Wireless Headset with Microphone (GP296)**

Thank you for purchasing the Logic3 PRO Command Wireless Headset with Microphone. As with all Logic3 products it has been built to the highest manufacturing standards and tested throughout its development, to ensure you get the best possible product. Please read through and familiarize yourself with this manual before you use the PRO Command Wireless Headset with Microphone.

#### **Contents**



PRO Command  
Wireless Headset



Receiver



RCA to 3.5mm




Xbox Connector




USB Charge Cable



3.5mm to 3.5mm




1. Microphone Connection LED status
2. Game/Chat Mode (Switches Game or Chat mode)
3. 2.5mm socket
4. Volume Controls
5. Microphone Mute Toggles ON/OFF
6. Power ON/OFF
7. Mini USB Charging Port
8. LED Charging Status



### **Set up of PRO Command Wireless Headset with Microphone**

No drivers are needed to set up the PRO Command Wireless Headset with PC/MAC/Xbox or PS3

1. Firstly you need to charge the Wireless Headset:



### **PC/MAC**

1. Turn on your PC.
2. Connect the receiver's USB connector to a spare USB port on your PC/MAC (Receiver's LED (Green) will flash slowly)
3. Ensure the headset is within 50cm of the receiver.
4. Press the ON/OFF button on your Headset to power it ON (Microphone connection LED (Green) will flash slowly – once every 2 seconds)
5. Pairing - First time connection only:-
  - a. Switch the Mode to 'CHAT', press and hold the Volume '+' and '-', simultaneously for 3 seconds.
  - b. Microphone connection Green LED will flash quickly
  - c. Receiver and Microphone connection LED will then light up permanently 'Green' (both of these LED status's show connection established)

Next time when you connect you will not have to complete step 5A-C, as it will automatically pair once you turn on the power.

6. Your PRO Command Wireless Headset is now ready to use, please set up the PC/MAC (Audio Set up) to use the Wireless PRO Command headset:-

### **PC**

- a. Right click 'Speaker' icon (Bottom right hand corner of Screen)
- b. Select 'Playback devices'
- c. A new Window will open

- d. Select 'Pro command Wireless Headset' and 'Apply'
- e. Next go to the 'Recording' Tab
- f. Select 'Pro command Wireless Headset' and 'Apply'


Above instructions are based on Windows 7, other Operating Systems may differ

## MAC

**Note: Game volume control will be de-activated while in PC / Mac mode**

### PS3

1. Turn on your PS3
2. Connect the receiver's USB connector to a spare USB port on your PS3 (Receiver's LED (Green) will flash slowly)
3. There are 2 ways to connect the receiver to your PS3:-



#### Method 1

- a. Using the 3.5mm to 3.5mm cable, connect one side of the 3.5mm jack to the rear of the receiver
- b. Connect the other 3.5mm jack to your headphone socket of your TV

#### Method 2

- a. Using the 3.5mm to RCA cable, connect one side of the 3.5mm jack to the rear of the receiver
- b. Connect the male RCA connectors Left/Right (White/Red) to the A/V input of your TV
- c. Connect the PS3 A/V cable Left/Right (White/Red) into the end of the RCA connectors (White/Red)
4. Ensure the headset is within 50cm of the receiver.
5. Press the ON/OFF button on your Headset to power it ON (Microphone connection LED (Green) will flash slowly – once every 2 seconds)

6. Pairing - First time connection only:-

- a. Switch the Mode to 'CHAT', press and hold the Volume '+' and '-', simultaneously for 3 seconds.
- b. Microphone connection LED (Green) will flash quickly
- c. Receiver and Microphone connection LED will then light up permanently 'Green' (both of these LED status's show connection established)


Next time when you connect you will not have to complete step 6A-C, as it will automatically pair once you turn on the power.

7. Your PRO Command Wireless Headset is now ready to use, please set up the PS3 (Audio Set up) to use the Wireless PRO Command headset:-

- a. Press the PS button on your PS3 controller to access the menu on the PS3
- b. Go to the 'Settings' menu on the PS3
- c. Select 'Accessory Devices'
- d. Select 'Audio Device Settings'
- e. Select 'Input Devices'
- f. Select the 'Pro Command Headset'
- g. Press 'X' to confirm
- h. Move to 'Output Devices'
- i. Select the 'Pro Command Headset'
- j. Press 'X' to confirm
- k. Select OK

Above instructions are based on firmware ver. 4.46, other firmware versions may differ

**Xbox / Xbox 360**



1. Turn on your Xbox/Xbox360
2. Connect the USB connector to a spare USB port on your Xbox (Microphone receiver LED (Green) will flash slowly)
3. Using the 3.5mm to RCA cable, connect one side of the 3.5mm jack into the rear of the receiver
4. Connect the male RCA connectors Left/Right (White/Red) to the A/V Input of your TV

5. Connect the Xbox A/V cable Left/Right (White/Red) into the RCA connectors.
  6. Connect the Xbox connector to your Xbox controller and connect the 2.5mm jack into the 2.5mm socket on the right side of the PRO Command headset.
  7. Ensure the headset is within 50cm of the receiver.
  8. Press the ON/OFF button on your Headset to power it ON (Microphone connection LED (Green) will flash slowly – once every 2 seconds)
  9. Pairing - First time connection only:-
    - a. Switch the Mode to 'CHAT', press and hold the Volume '+' and '-', simultaneously for 3 seconds.
    - b. Microphone Connection LED (Green) will flash quickly
    - c. Receiver and Microphone connection LED will then light up permanently 'Green' (both these LED status shows connection established)
- Next time when you connect you will not have to complete step 9A-C, as it will automatically pair once you turn on the power.
10. Your PRO Command Wireless Headset is now ready to use.
  11. Please ensure you have chosen the correct settings in your Xbox/Xbox360 menu to allow you to use the Pro Command Headphones.

**Force connection - If the headset does not respond to any commands, please carryout the following:**

1. Close down the application used i.e. music player, or game on console.
2. Ensure the headset is within 50cm of the receiver.
3. Switch the Mode to CHAT and press and hold the Volume '+' and '-', simultaneously for 3 seconds.
4. Microphone connection LED (Green) will flash quickly
5. Receiver and microphone connection LED will then light up permanently 'Green' (both these LED status shows connection established)

**Game and Chat Modes**

To offer comfort and practicality, you can adjust the volume settings individually for Gaming or Chat modes.

**Low battery Alert:**

When the battery is low, the microphone connection LED (Green) indicator will flash once every 1 second, to indicate the low battery status.

**Sleep mode:**

When the headset has not been used for three minutes or more, the headset will automatically go into sleep mode. The Microphone connection LED (Green) will flash once every five seconds. To resume normal function, press the Volume "+" and "-" buttons simultaneously this will exit the sleep mode.

**Anti-Jamming**

With auto frequency adjustment technology, the headset will adjust the frequency to unoccupied frequency to avoid jamming from the common jamming source of WIFI, Microwave, 2.4G wireless telephone.

## **Trouble Shooting**

<b>Problem</b>	<b>What Should I do?</b>
Game volume not functioning	Game volume control will be de-activated while in PC / Mac mode
Chat volume not functioning	Chat volume control will be de-activated while in PC / Mac mode or connected to a TV
Sound is coming through the PC not the headphones	<p>You will need to set the audio properties on the PC.</p> <ol style="list-style-type: none"><li>1. At the bottom right corner of your PC screen, right click the speaker icon to enter the audio properties</li><li>2. Select playback devices..</li><li>3. A window will then pop up, select the PRO Command Wireless Headset in the list.</li><li>4. Select the 'Recording' tab and choose the PRO Command headset.</li></ol> <p>Note: The above instruction is for windows 8 other OS formats may vary.</p>

## **Specifications:**

1. Compatible with PC/PS3/XBOX360
2. 2.4GHz Technology with auto frequency adjustment for Anti-Jamming.
3. Operational range up to 7M
4. Built-in Lithium-ion rechargeable battery: 3.7V/780mAh
5. Working current: <50mA, sleeping current: 200uA
6. Approximately 10 hours per one charge



**L3i Ltd**  
**Rhodes Way, Watford Herts**  
**WD24 4YW UK**  
**Tel: +44 (0)1923 471020**  
**<http://www.gamespower.com>**  
**E-mail: [support@l3-i.com](mailto:support@l3-i.com)**

