



# MESH BAG & EGO GRIP REPLACEMENT INSTRUCTIONS

---

- ① Remove two small screws in EGO Grip
- ② Where hoop frame exists the EGO Grip:
  - Take flat slotted screw driver and slide it between Grip and aluminum frame
- ③ Pry the two Grip halves apart:
  - Apply constant pressure until two halves separate (pins on the interior will begin to “unzip”)
- ④ Remove 4 screws that hold hoop frame into aluminum core body
- ⑤ Remove hoop frame
- ⑥ Take old mesh bag off and restring hoop with new mesh bag
- ⑦ Insert hoop back into aluminum core body
- ⑧ Replace 4 screws (be sure not to over tighten / if over tightened run the risk of stripping aluminum threads)
- ⑨ Replace EGO Grip:
  - Will have to use some pressure to get it to seat closed (small vice usually works well)
- ⑩ Replace two small screws at the top of EGO Grip

---

**HAVE QUESTIONS PLEASE EMAIL US AT:** [support@egofishing.com](mailto:support@egofishing.com) **OR GIVE US A CALL AT:** 1-800-698-6841

---