

# X4

## REAR MOUNTING SYSTEM



**1** PART A  
LARGE  
MOUNTING  
ARM

**6** PART G  
LONG BLACK  
FLAT HEAD  
SCREW

**2** PART B  
MEDIUM  
ADJUSTABLE  
ARM

**7** PART H  
SHORT  
BLACK  
FLAT HEAD  
SCREW

**3** PART C  
SMALL  
BASE ARM

**8** PART I  
WASHER  
(EXTRA PART)

**4** PART D  
L SHAPE  
BRACKET

**9** PART L  
X-4 MOUNTING  
BLOCK +  
4 BLACK  
SCREWS

**5** PART F  
MEDIUM  
BLACK  
ROUND HEAD  
SCREWS

**10** TOOL

# X4

## REAR MOUNTING SYSTEM



1

Take LARGE MOUNTING ARM (PART A) and using 2 MEDIUM BLACK ROUND HEAD SCREWS (PART F), attach the L SHAPE BRACKET (PART D) as shown in Fig A.




Fig. A

2

Take the SMALL BASE ARM (PART C) and using 2 MEDIUM BLACK ROUND HEAD SCREWS (PART F), attach to the L SHAPE BRACKET (PART D) as shown in Fig B.



Fig. B

3

Take the MEDIUM ADJUSTABLE ARM (PART B) and slide into SMALL BASE ARM (PART C). Adjust length and once the arm is in your desired position take the SHORT BLACK FLAT HEAD SCREW (PART H) and fasten into the SMALL BASE ARM (PART B) Refer to Fig C.



Fig. C



# REAR MOUNTING SYSTEM



## X-4

Remove the 4 black screws from on top of your X-4 light. Now you can simply place and screw the X-4 MOUNTING BLOCK (PART L) onto the X-4 using the BLACK SCREWS provided. You may now take the X-4 and using the LONG BLACK FLAT HEAD SCREW (PART G) fasten to the MEDIUM ADJUSTABLE ARM (PART B). Refer to Fig G and H



Fig. G



Fig. H

## NOTES AND HANDY HINTS

- There may be some extra screws in each package.
- The SMALL SILVER WASHER (PART I) is only needed when you are extending the mount very far out into your aquarium. To use this, simply add onto the top screw on the back of the LARGE MOUNTING ARM. Please note there is already 1 washer installed underneath this screw.

