




# BLAZE X MINI + X4 REAR MOUNTING SYSTEM





- 1** **PART A**  
LARGE MOUNTING ARM



- 2** **PART B**  
MEDIUM ADJUSTABLE ARM



- 3** **PART C**  
SMALL BASE ARM


- 4** **PART D**  
L SHAPE BRACKET


- 5** **PART E**  
MINI PLATE + SILVER SCREWS


- 6** **PART F**  
MEDIUM BLACK ROUND HEAD SCREWS


- 7** **PART G**  
LONG BLACK FLAT HEAD SCREW



- 8** **PART H**  
SHORT BLACK FLAT HEAD SCREW


- 9** **PART I**  
WASHER (EXTRA PART)


- 10** **PART J**  
DUAL MOUNTING BAR


- 11** **PART K**  
LONG SILVER FLAT HEAD SCREWS + FASTENER


- 12** **PART L**  
X-4 MOUNTING BLOCK + 4 BLACK SCREWS


- 13** **TOOL**



# BLAZE X MINI + X4 REAR MOUNTING SYSTEM



1

Take LARGE MOUNTING ARM (PART A) and using 2 MEDIUM BLACK ROUND HEAD SCREWS (PART F), attach the L SHAPE BRACKET (PART D) as shown in Fig A.




Fig. A

2

Take the SMALL BASE ARM (PART C) and using 2 MEDIUM BLACK ROUND HEAD SCREWS (PART F), attach to the L SHAPE BRACKET (PART D) as shown in Fig B.



Fig. B

3

Take the MEDIUM ADJUSTABLE ARM (PART B) and slide into SMALL BASE ARM (PART C). Adjust length and once the arm is in your desired position take the SHORT BLACK FLAT HEAD SCREW (PART H) and fasten into the SMALL BASE ARM (PART B) Refer to Fig C.



Fig. C



# BLAZE X MINI + X4 REAR MOUNTING SYSTEM



FROM THIS POINT ONWARDS, YOUR INSTALLATION ACCESSORIES AND INSTRUCTIONS WILL VARY DEPENDING ON YOUR SPECIFIC MOUNTING SETUP.

## SINGLE BLAZE X MINI

Take the MINI PLATE (PART E) and using the LONG BLACK FLAT HEAD SCREW (PART G) fasten to the MEDIUM ADJUSTABLE ARM (PART B). You may now screw your BLAZE X MINI onto the MINI PLATE (PART E) using the 2 SILVER SCREWS provided. Refer to Fig D



Fig. D

## DUAL BLAZE X MINI

Take the DUAL MOUNTING BAR (PART J) and using the LONG SILVER FLAT HEAD SCREWS + FASTENER (PART K) fasten to the MEDIUM ADJUSTABLE ARM (PART B). You may now screw both your BLAZE X MINI's onto the MINI PLATE (PART E) using the 2 SILVER SCREWS provided. Refer to Fig E and F



Fig. E



Fig. F

# BLAZE X MINI + X4 REAR MOUNTING SYSTEM



## X-4

Remove the 4 black screws from on top of your X-4 light. Now you can simply place and screw the X-4 MOUNTING BLOCK (PART L) onto the X-4 using the BLACK SCREWS provided. You may now take the X-4 and using the LONG BLACK FLAT HEAD SCREW (PART G) fasten to the MEDIUM ADJUSTABLE ARM (PART B). Refer to Fig G and H



Fig. G



Fig. H

## NOTES AND HANDY HINTS

- There may be some extra screws in each package.
- The SMALL SILVER WASHER (PART I) is only needed when you are extending the mount very far out into your aquarium. To use this, simply add onto the top screw on the back of the LARGE MOUNTING ARM. Please note there is already 1 washer installed underneath this screw.

# BLAZE X MINI + X4 REAR MOUNTING SYSTEM



## ➔ COMPLETE SET UPS

One BLAZE X MINI for your  
nano reef



Add another BLAZE X MINI  
with the Dual Mount for  
extra power



Or Upgrade to the ILLUMAGIC  
X4 for superior spread  
and PAR

