



ATMOSFX™

MEDIA PLAYER



USER MANUAL

Please read carefully before using the media player

MADE IN CHINA

SECTION 1: PRODUCT SPECIFICATIONS

1.1 INCLUDED COMPONENTS	2
1.2 AV CONNECTIONS	2
1.3 TECHNICAL SPECIFICATIONS	3
1.4 MEDIA PLAYER VISUAL GUIDE	4
1.5 REMOTE CONTROL BUTTON FUNCTIONS	4
1.6 IR MOTION SENSOR SPECIFICATIONS	5

SECTION 2: USAGE GUIDE

2.1 STARTING THE MEDIA PLAYER	6
2.2 PLAYING DIGITAL DECORATION CONTENT	7
2.3 PLAYING MUSIC CONTENT	8
2.4 DISPLAYING PHOTO CONTENT	8
2.5 SETTING UP THE IR MOTION SENSOR	8

SECTION 3: SETTINGS MENU

3.1 PICTURE SETTINGS	9
3.2 TIME SETTINGS	9
3.3 LANGUAGE AND OUTPUT OPTIONS	10
3.4 SYSTEM SETTINGS	10
3.5 USB SETTINGS	11

SECTION 4: COMPLIANCE INFORMATION

4.1 US FCC STATEMENT	11
4.2 INDUSTRY CANADA STATEMENT	12
4.3 ATMOSFX INC. LIMITED WARRANTY	12

SECTION 1: PRODUCT SPECIFICATIONS

1.1 INCLUDED COMPONENTS

- AtmosFX Media Player
- IR Motion Sensor (with hook-and-loop adhesive tape strip)
- Remote Control (2xAAA batteries, not included)
- 6-inch HDMI Cable
- AC-DC Power Adapter (UL/CUL for US/Canada)



1.2 AUDIO/VIDEO CONNECTIONS

1. **HDMI Video Output:** Connect one end of included HDMI cable to HDMI output terminal of this player and connect the other end to your TV or projector.
2. **A/V Video Output:** Connect single black plug of user-provided A/V cable to A/V output terminal of this player and connect the other end to your TV or projector based on the jack color (video-yellow; audio-red and white).
3. **Component Video Output (YPbPr) :** Connect one end of user-provided component video cable to YPbPr output terminal of this player and connect the other end to your TV or projector based on the jack color (green, blue and red).

1.3 TECHNICAL SPECIFICATIONS


Power	Positive inside and negative outside, 5V/1A
File System	FAT32, NTFS
Video Outputs	Component YPbPr, AV, HDMI1.3
Audio Outputs	Analog stereo, digital audio HDMI1.3
Video Formats	AVI/ MPG/ MPEG/ XVID/ VOB/ DAT/ MP4/ TS/ M2TS/ MKV/ H.264/ RM/ RMVB and more
Audio Formats	PCM/ DTS/ AC3/ MP3/ RA/ AMR/ MP3/ WMA/ OGG/ APE
Picture Formats	JPG/BMP/PNG/GIF/TIFF
Subtitle Formats	SMI/ ASS/ SSA/ SRT/ SUB/ PGS/ SUB+IDX
Language	Choice of 8 languages
USB Port	USB HOST 2.0
Source Formats	SD/ SDHC/ MMC Card
Indication Light	Red Light when Off Green Light when Stand By/Working
Working Environment	Working Temperature: 14 ~ 113°F Working Humidity: <90% Storing Temperature: -4 ~ 158°F Working Humidity:<95%

1.4 MEDIA PLAYER VISUAL GUIDE



- 1.HDMI
- 2.YPbPr
3. AV
4. DC-5V Power Input
5. SD Card Slot
6. Power Indicator
7. IR Motion Sensor Jack
8. Remote Control IR Receiver
9. USB Slot

1.5 REMOTE CONTROL BUTTON FUNCTIONS





No.	Button	Function
1	Sensor	Turn on/off IR sensor
2	VOL-	Volume Down
3	Movie	Movie mode
4	⏮	Fast rewind
5	⏪	Previous track
6	▲	Up
7	◀	Left
8	▼	Down
9	⏻	Power: Standby-On / Off
10	Repeat	Random/Single Repeat/All Repeat
11	⏸	Mute: On/Off
12	Photo	Photo mode
13	⏩	Play/Pause
14	MENU	Switch to main menu
15	EXIT	Stop playing and back to last page
16	OK	Enter and confirm
17	VOL+	Volume up
18	Music	Music mode
19	⏭	Fast forward
20	⏩	Next track
21	▶	Right

1.6 IR MOTION SENSOR SPECIFICATIONS

EFFECTIVE RANGE: Approximately 10 feet (3 meters)

DETECTION AREA: 100 degree conical range



SECTION 2: USAGE GUIDE


2.1 STARTING THE MEDIA PLAYER

Connect the AtmosFX Media Player to your projector or TV, plug in the provided A/C adapter and, on your TV or Projector, select the appropriate input source (eg. HDMI).

Insert your SD Card or USB drive into the media player.

Note: If both a USB drive and SD card are inserted then use the arrow buttons ◀/▶ to switch to your desired input source.

You will then be greeted with the Main Menu “Home” screen.



2.2 PLAYING DIGITAL DECORATION (OR VIDEO) CONTENT

1. Press “Movie” on the remote control, or select the “DIGITAL DECORATIONS” icon and then press the “OK” button.
2. With the arrow buttons ▼/▲, navigate to the Digital Decoration you want to play.
3. Press the “OK” button to select the Digital Decoration. File information plus sample video playback will show on the right side of the screen for your chosen file.



4. Press the play button  to play the file in full screen.

Note: Press the “EXIT” button to exit the full screen display and return to the file directory.

Note: Press the "REPEAT" button sequentially to choose between "Single Repeat / All Repeat / Random Repeat / Repeat Off".


2.3 PLAYING MUSIC CONTENT

1. Press “Music” on the remote control, or select the “MUSIC” icon and then press the “OK” button.
2. With the arrow buttons ▼/▲, navigate to the folder/file you want to play.
3. Press the “OK” button to select and play the music file.
4. Press the “EXIT” button to return to the File Directory.

2.4 DISPLAYING PHOTO CONTENT


1. Press “Photo” on the remote control, or select the “PHOTO” icon and then press the “OK” button.
2. With the arrow buttons ▼/▲, navigate to the folder/file you want to view.
3. Press the “OK” button to select and display the photo in full screen.
4. Press the ◀◀ / ▶▶ button to display previous/next photo file.
5. Press the “EXIT” button to return to the File Directory.

2.5 SETTING UP THE IR MOTION SENSOR

1. While playing a Digital Decoration, press the “Sensor” button on the remote control. You will then see the motion sensor icon  briefly display on the screen.
2. Press the “Repeat” button on the remote control until **Single Repeat** is selected.
3. The media player will enter into standby mode after the

current video finishes playing.

4. When the motion sensor is triggered, the media player will automatically play the chosen Digital Decoration.

Note: To turn off the motion sensor, first press the "Sensor" button on the remote control. You will see the motion sensor off icon  briefly display on the screen. Then you may disconnect the IR motion sensor.

SECTION 3: SETTINGS

To select the Settings menu, press the "MENU" button on the remote control.

3.1 PICTURE SETTINGS

- **ASPECT RATIO:** 16:9Wide Screen, 16:9 Pillar Box, 16:9 Pan & Scan, 4:3 Letter Box, 4:3 Pan & Scan, 4:3 Full, Auto
- **RESOLUTION:** 480i, 480p,720p, 1080i,1080p (60hz)
- **TV FORMAT:** NTSC, PAL

3.2 TIME SETTINGS

- **SLEEP:** 1~12hours, Off

3.3 LANGUAGE AND OUTPUT OPTIONS

- **OSD LANGUAGE:** English, Czech, Danish, French, German, Italian, Portuguese, Spanish, Swedish
- **SUBTITLE LANGUAGE:** English, Spanish, Greek, French, Croatian, Italian, Hungarian, Dutch, Norwegian, Polish, Portuguese, Russian, Romanian, Slovene, Serbian, Finnish, Swedish, Bulgarian, Gaelic, Welsh, Catalan, Czech, Danish, German, Off (only works with relevant video files)
- **AUDIO LANGUAGE:** English, Spanish, Greek, French, Croatian, Italian, Hungarian, Dutch, Norwegian, Polish, Portuguese, Russian, Romanian, Slovene, Serbian, Finnish, Swedish, Bulgarian, Gaelic, Welsh, Catalan, Czech, Danish, German (only works with relevant video files)
- **DIGITAL AUDIO OUTPUT:** PCM, RAW HDMI On, RAW HDMI Off, Off

3.4 SYSTEM SETTINGS

- **PARENTAL GUIDANCE:** Factory set (cannot be modified)
- **SET PASSWORD:** Factory set (cannot be modified)
- **RESTORE FACTORY DEFAULT:** Start, Quit
- **INFORMATION:** Factory set (cannot be modified)
- **SOFTWARE UPDATE:** Factory set (cannot be modified)

3.5 USB SETTINGS

- **MULTIMEDIA:** Goes to Main Menu
- **PHOTO CONFIGURE:** Slide Display Time, Slide Mode, Aspect Ratio
- **MOVIE CONFIGURE:** Subtitle Specific Size, Subtitle Background Color, Subtitle Font Color

SECTION 4: COMPLIANCE INFORMATION

4.1 US FCC STATEMENT

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Warning: You are cautioned that changes or modification not expressly approved by AtmosFX Inc. could void your authority to operate the equipment.

4.2 INDUSTRY CANADA STATEMENT

- This Class B digital apparatus complies with Canadian ICES-003.
- Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

4.3 ATMOSFX INC. LIMITED WARRANTY

AtmosFX Inc. warrants all AtmosFX products that are subject to this Limited Warranty (“Warranted Products”) against defects in material and workmanship for 30 days after receipt of shipment. This Limited Warranty extends to the first consumer purchaser of the applicable Warranted Product from AtmosFX. Only items that have been purchased directly from AtmosFX are governed by this Limited Warranty. AtmosFX products purchased through other retailers must be returned in accordance with that retailer’s respective replacement and refunds policy.

All AtmosFX Limited Warranties are non-transferable. For clarity, this Limited Warranty does not apply to resellers of AtmosFX products.

Products that are not Warranted Products include: AtmosFX digital downloads and other non-physical goods (including any software embedded in an AtmosFX product); AtmosFX products not purchased directly from www.AtmosFX.com; AtmosFX products purchased as “Final Sale” items; products featuring AtmosFX content or using AtmosFX registered trademarks but not produced by AtmosFX Inc.

AtmosFX's Limited Warranty shall not apply to product that has been damaged through misuse, abuse, accident, modifications, alterations, neglect, mishandling, or faulty installation.

If you believe an AtmosFX product you purchased is subject to a manufacturer defect and you are within the 30-day warranty period, please contact us, using the contact information set forth at the end of this Limited Warranty or visit <http://support.atmosfx.com/> and complete the "Contact Us" form. A representative will contact you and direct you through the warranty process.

Do not return products to AtmosFX without first contacting a support representative as this may void your warranty claim. Any products shipped back to AtmosFX will be at the expense of the customer. Cost of shipping for warranty replacements back to the customer will be paid for by AtmosFX.

Disclaimer: Limitation of Liability

TO THE EXTENT PERMISSIBLE BY APPLICABLE LAW, THIS LIMITED WARRANTY AND ANY IMPLIED WARRANTIES ARE YOUR EXCLUSIVE WARRANTIES AND REPLACE ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, THE EXCLUSION OF IMPLIED WARRANTIES, OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE

LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE AND JURISDICTION TO JURISDICTION.

AtmosFX's Limited Warranty is governed by the laws of the State of Washington. **For more information about the Limited Warranty, visit www.AtmosFX.com.**

Warrantor:

AtmosFX Inc

Seattle, WA 98103

info@atmosfx.com