

ASSEMBLY INSTRUCTION

JUST SPEAK
WIRELESS COMMUNICATION
Bluetooth® **EVO**



Remove the inner linings as indicated in the communicator's user manual.



Place the right speaker (R) in its seat on the velcro.




Repeat the operations performed for the right (R) speaker for positioning the left (L).



Place the microphone base under the chinstrap between EPS and shell. Use the additional microphone support included by positioning it as the image.

ASSEMBLY INSTRUCTION

JUST SPEAK
WIRELESS COMMUNICATION
Bluetooth® **EVO**



Adjust the microphone's position by deforming its boom.

WARNING: check that the triangle on the microphone is facing the mouth.



Assemble the inner linings making sure that the microphone, remote control and USB cable are accessible from outside the helmet.

Place the USB socket between the inner linings and the shell.



Stick the remote control on the side of the shell verifying the correct adhesion.