



- 1 Z34FN** * E28-E34-E38 bottom-shell black

- 2 Z101** Push set protection

- 3 Z103** * Top-case hinge

- 4 Z104** Square two holes

- 5 Z105** Key lock plate

- 6 Z106** Bolt

- 7 Z107** Bag yarn

- 8 Z108** Top-case push button red

- 9 Z109** Long bolt springs

- 10 Z112R** Red pulley

- 11 Z118** ▲ Plate two holes

- 12 Z119** Top-case reflector

- 13 Z120-28** * Series of E28 stickers

- 14 Z158** Spare elastic belt

- 15 Z159R** Bag lock lining

- 16 Z1237** Push button spring with washer

- 17 Z193** Hinge pin 62 mm

 - 18 Z195** Hinge pin 78 mm

 - 19 Z210** Chrome bushing for lock set

 - 20 Z140R** Lock key

 - 21 Z110** Plate four holes

- * ITEM OUT OF STOCK